

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:
400416048

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322 Contact Name: Leah Perkins
 Name of Operator: NOBLE ENERGY INC Phone: (970) 286-5925
 Address: 1625 BROADWAY STE 2200 Fax: (970) 304-5099
 City: DENVER State: CO Zip: 80202 Email: LPerkins@nobleenergyinc.com

For "Intent" 24 hour notice required, Name: MONTOYA, JOHN Tel: (970) 3974124
COGCC contact: Email: john.montoya@state.co.us

API Number 05-123-35654-00 Well Number: 07-01
 Well Name: CON GQ
 Location: QtrQtr: NENE Section: 7 Township: 10N Range: 61W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: _____
 Field Name: JUPITER Field Number: 42750

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.854250 Longitude: -104.242340
 GPS Data:
 Date of Measurement: 03/06/2012 PDOP Reading: 1.8 GPS Instrument Operator's Name: Robert Daley
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: Drill pipe became stuck in this wellbore while attempting to pump a cement plug after determining that the well was dry. The drill pipe was cut off at 8006'.

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	13+1/2	9+5/8	36.0	1,104	228	1,104	0	VISU
1ST	8+3/4	7+0/8	26.0	9,000	1,089	9,000	6,000	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7830 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 5000 ft. with 125 sacks. Leave at least 100 ft. in casing 4950 CICR Depth

Perforate and squeeze at 2500 ft. with 125 sacks. Leave at least 100 ft. in casing 2450 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 500 sacks half in. half out surface casing from 1200 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

CIBP @ 7830' with 2 sx cement on top is currently in hole. It was set on 7/20/2012.

The following cement plugs were pumped on 7/19/2012: 9611' - 10,372' (134 sx) and 8783' - 9589' (134 sx). They are shown on the attached wellbore diagrams.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Julie Ottoson

Title: Base Production Tech Date: _____ Email: JOttoson@nobleenergyinc.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

Attachment Check List

Att Doc Num	Name
400416414	WELLBORE DIAGRAM
400416415	PROPOSED PLUGGING PROCEDURE
400416416	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)