

**FORM**  
**6**  
Rev  
12/05

**State of Colorado**  
**Oil and Gas Conservation Commission**

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
Document Number:  2091162			
Date Received:  06/30/2014			

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.  
A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 87195 Contact Name: DAVE REBOL  
 Name of Operator: TEXAS TEA OF COLORADO LLC DBA TEXAS TEA Phone: (970) 8679007  
 Address: 14405 W. COLFAX #298 Fax: (970) 8678374  
 City: LAKEWOOD State: CO Zip: 80401 Email: DAVEREBOL@HOTMAIL.COM

**For "Intent" 24 hour notice required,** Name: JOHNSON, RANDELL Tel: (303) 815-9641  
**COGCC contact:** Email: randell.johnson@state.co.us

API Number 05-123-10551-00 Well Name: NELSON Well Number: 1-A  
 Location: QtrQtr: SWNW Section: 32 Township: 2N Range: 68W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: \_\_\_\_\_  
 Field Name: SPINDLE Field Number: 77900

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.097470 Longitude: -105.034500  
 GPS Data:  
 Date of Measurement: 02/18/2013 PDOP Reading: 1.4 GPS Instrument Operator's Name: CRAIG BURKE, PLS  
 Reason for Abandonment:  Dry  Production for Sub-economic  Mechanical Problems  
 Other \_\_\_\_\_  
 Casing to be pulled:  Yes  No Estimated Depth: 3424  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
SHANNON	4838	4856			
SUSSEX	4410	4418			
Total: 2 zone(s)					

**Casing History**

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	711	600	0	0	
1ST	7+7/8	4+1/2	10.5	4,999	250	0	0	

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4350 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 3424 ft. to 3324 ft. Plug Type: STUB PLUG Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set 100 sacks half in. half out surface casing from 751 ft. to 600 ft. Plug Tagged:   
 Set 10 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: DAVE REBOL  
 Title: AGENT Date: 6/27/2014 Email: DAVEREBOL@HOTMAIL.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SCHLAGENHAUF, MARK Date: 7/8/2014

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: 1/7/2015

COA Type	Description
	1) Submit Form 42 electronically to COGCC 48 hours prior to MIRU. 2) If unable to pull casing contact COGCC for plugging modifications. 3) If maintain circulation do not need to tag stub plug@3424'. 4) For 751' plug: pump plug and displace, shut-in, WOC 4 hours and tag plug – must be 660' or shallower. If shoe plug not circulated to surface then place 10 sx inside casing at surface. Leave at least 100' for each plug. 5) Properly abandon flowlines as per Rule 1103. File electronic Form 42 once abandonment complete.

## Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
2091162	FORM 6 INTENT SUBMITTED
2091163	WELLBORE DIAGRAM

Total Attach: 2 Files

## General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Well Completion Reports dated 5/13/1982 & 6/27/1985.	7/8/2014 10:52:18 AM

Total: 1 comment(s)