



BRADENHEAD TEST REPORT

Step 1. Record all tubing and casing pressures as found.
Step 2. Sample now, if intermediate or surface casing pressure >25 psi. In sensitive areas, 1 psi.
Step 3. Conduct Bradenhead test.
Step 4. Conduct intermediate casing test.
Step 5. Send report to BLM within 30 days and to OGCC within 10 days. Include wellbore diagram if not previously submitted or if wellbore configuration has changed since prior program. Attach gas and liquid analyses if sampled.

1. OGCC Operator Number: _____
2. Name of Operator: _____ 3. BLM Lease No: _____
4. API Number: _____ 5. Multiple completion? ☐ Yes ☐ No
6. Well Name: _____ Number: _____
7. Location (QtrQtr, Sec, Twp, Rng, Meridian): _____
8. County: _____ 9. Field Name: _____
10. Minerals: ☐ Fee ☐ State ☐ Federal ☐ Indian

11. Date of Test: _____
12. Well Status: ☐ Flowing ☐ Shut In
☐ Gas Lift ☐ Pumping ☐ Injection
☐ Clock/Intermitter
☐ Plunger Lift
13. Number of Casing Strings: _____
☐ Two ☐ Three ☐ Liner?

14. STEP 1: EXISTING PRESSURES

Record all pressures as found	Tubing: _____ Fm: _____	Tubing: _____ Fm: _____	Prod. Casing: _____ Fm: _____	Intermediate Csg: _____	Surface Casing: _____
-------------------------------	----------------------------	----------------------------	----------------------------------	-------------------------	-----------------------

15. STEP 2: See instructions above.

16. STEP 3: BRADENHEAD TEST

Buried valve? ☐ Yes ☐ No Confirmed open? ☐ Yes ☐ No
With gauges monitoring production, intermediate casing and tubing pressures, open surface casing (bradenhead) valve (if no intermediate casing, monitor only the production casing and tubing pressures.) Record pressures at five minute intervals. Define characteristics of flow in "Bradenhead Flow" column using letter designations below:
O = No Flow; C = Continuous; D = Down to 0; V = Vapor
H = Water H2O; M = Mud; W = Whisper; S = Surge; G = Gas

Elapsed Time (Min:Sec)	Fm: _____ Tubing:	Fm: _____ Tubing:	Production Casing PSIG	Intermediate Casing PSIG	Bradenhead Flow:
00:					
05:					
10:					
15:					
20:					
25:					
30:					

BRADENHEAD SAMPLE TAKEN?
☐ Yes ☐ No ☐ Gas ☐ Liquid
Character of Bradenhead fluid: ☐ Clear ☐ Fresh
☐ Sulfur ☐ Salty ☐ Black
☐ Other: (describe) _____
Sample cylinder number: _____

Note instantaneous Bradenhead PSIG at end of test: >

17. STEP 4: INTERMEDIATE CASING TEST

Buried valve? ☐ Yes ☐ No Confirmed open? ☐ Yes ☐ No
With gauges monitoring production casing and tubing pressures, open the intermediate casing valve. Record pressures at five minute intervals. Characterize flow in "Intermediate Flow" column using letter designations below:
O = No Flow; C = Continuous; D = Down to 0; V = Vapor
H = Water H2O; M = Mud; W = Whisper; S = Surge; G = Gas

Elapsed Time (Min:Sec)	Fm: _____ Tubing:	Fm: _____ Tubing:	Production Casing PSIG	Intermediate Casing PSIG	Intermediate Flow:
00:					
05:					
10:					
15:					
20:					
25:					
30:					

INTERMEDIATE SAMPLE TAKEN?
☐ Yes ☐ No ☐ Gas ☐ Liquid
Character of Intermediate fluid: ☐ Clear ☐ Fresh
☐ Sulfur ☐ Salty ☐ Black
☐ Other: (describe) _____
Sample cylinder number: _____

Note instantaneous Intermediate Casing PSIG at end of test: >

18. Comments: _____

19. STEP 5: See instructions above.

I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct, and complete.

Test Performed by: _____ Title: _____ Phone: _____

Signed: _____ Title: _____ Date: _____

WITNESSED BY: _____ Title: _____ Agency: _____