

FORM
6Rev
12/05State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401127012

Date Received:

10/10/2016

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10112

Contact Name: Rachel Grant

Name of Operator: FOUNDATION ENERGY MANAGEMENT LLC

Phone: (918) 526-5592

Address: 16000 DALLAS PARKWAY #875

Fax: (918) 585-1660

City: DALLAS State: TX Zip: 75248-

Email: regulatory@foundationenergy.com

For "Intent" 24 hour notice required,

Name: Welsh, Brian

Tel: (719) 325-6919

COGCC contact:

Email: brian.welsh@state.co.us

API Number 05-125-07580-00

Well Name: EBELER/PETERSON

Well Number: 13-5

Location: QtrQtr: NWSW Section: 5 Township: 5S Range: 43W Meridian: 6

County: YUMA

Federal, Indian or State Lease Number:

Field Name: BONNY

Field Number: 7325

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.650596

Longitude: -102.211728

GPS Data:

Date of Measurement: 08/24/2009

PDOP Reading: 2.3

GPS Instrument Operator's Name: Mary Nicklos

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes☒ No

Estimated Depth:

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	1438	1474			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+7/8	7	23	214	80	214	0	VISU
1ST	6+1/4	4+1/2	9.5	1,590	100	1,590	654	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1388 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 330 ft. with 50 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set 10 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Rachel Grant

Title: HSE Regulatory Date: 10/10/2016 Email: regulatory@foundationenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK Date: 11/9/2016

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 5/8/2017

COA Type	Description
	<p>Prior to starting plugging operations, perform a Bradenhead Test. If pressure remains at the conclusion of the test or any liquids were present see Sampling Requirements below. Submit Form 17 within 10 days.</p> <p>Sampling requirements: If a well has a bradenhead pressure greater than 25 PSI and/or flowed liquids from the Bradenhead then sampling is required as follows: Collect a sample of both the production and bradenhead gas and submit for laboratory analysis of the gas composition and stable isotope analysis including the d13C1, d13C2, d13C3, d13C4, d13NC4 d13C5 , d13NC5, d13C6+ (if possible), and dDC1. Submit analytical results to the COGCC environmental database in an accepted Electronic Data Deliverable (EDD) format.</p> <p>If water is encountered in the bradenhead during testing then collect samples and submit for the laboratory analysis of major anions (chloride, carbonate, bicarbonate, and sulfate), cations (sodium, potassium, calcium, and magnesium) total dissolved solids (TDS), BTEX, DRO, GRO and dissolved gases (RSK 175). If there is a limited amount of water available then anions, cations and BTEX should be given first priority. Data from bradenhead water samples shall be submitted to the COGCC environmental database in an accepted Electronic Data Deliverable (EDD) format.</p>
	<p>Note changes to submitted form.</p> <ol style="list-style-type: none"> 1) Provide 48 hour notice of MIRU via electronic Form 42. 2) Shoe plug (Perf & squeeze 50 sx at 330'): Tag plug 50' above surface casing shoe, if not circulated to surface. 3) Surface plug: Cement from 50' to surface in casing and annulus. 4) Properly abandon flowlines per Rule 1103. File Form 42 when done. 5) Abandoned well marker shall be inscribed with the well's legal location, well name and number, and API Number (Rule 319.a.(5)).

Attachment Check List

Att Doc Num	Name
401127012	FORM 6 INTENT SUBMITTED
401127032	WELLBORE DIAGRAM
401127033	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group	Comment	Comment Date
Engineer	Moved CIBP proposed at 1430' up to 1388' (50' above top perf). Added 10 sk plug at surface.	11/09/2016
Public Room	Document verification complete 10/17/16	10/17/2016

Total: 2 comment(s)