

Document Number:
401351416

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 75027 Contact Name: AZUCENA TORRES

Name of Operator: ROSEWOOD RESOURCES INC Phone: (970) 848-2228

Address: 2101 CEDAR SPRINGS RD STE 1500 Fax: (970) 848-2245

City: DALLAS State: TX Zip: 75201 Email: AZUCENATORRES@ROSEWD.COM

For "Intent" 24 hour notice required, Name: Welsh, Brian Tel: (719) 325-6919

COGCC contact: Email: brian.welsh@state.co.us

API Number 05-125-06504-00

Well Name: ROGERS Well Number: 1-19

Location: QtrQtr: NWNW Section: 19 Township: 2S Range: 45W Meridian: 6

County: YUMA Federal, Indian or State Lease Number: _____

Field Name: MILDRED Field Number: 54975

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.872941 Longitude: -102.462945

GPS Data:
Date of Measurement: 10/15/2010 PDOP Reading: 2.4 GPS Instrument Operator's Name: James Krehmeyer

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems

Other _____

Casing to be pulled: Yes No Estimated Depth: _____

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2196	2138			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+1/4	7+5/8	30	183	130	183	0	CALC
1ST	6+1/2	2+7/8	6.5	2,341	70	2,341	1,641	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 10 sks cmt from 2196 ft. to 2288 ft. Plug Type: CASING Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at 233 ft. with 45 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

INTENT TO ABANDON: PUMP 10 SACKS OF CEMENT DOWN 2 7/8" CASING THROUGH PERFORATION. WAIT 6 HRS RUN IN HOLE WITH WIRELINE TO TAG CEMENT 50' ABOVE PERFORATIONS. PERFORATE SQUEEZE HOLES 50' BELOW SURFACE CASING (233'). PUMP 45 SACKS OF CEMENT DOWN 2 7/8" CASING AND UP ANNULUS TO SURFACE. CUT OFF CASING 5' BELOW GROUND LEVEL, WELD PLATE AND BACKFILL.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: AZUCENA TORRES
 Title: HSE & REGULATORY REP Date: _____ Email: AZUCENATORRES@ROSEWD.COM

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type	Description

Attachment Check List

Att Doc Num

Name

401354785	WELLBORE DIAGRAM
-----------	------------------

401354788	WELLBORE DIAGRAM
-----------	------------------

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)