

FORM
6Rev
05/18State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402166810

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 100322

Contact Name: Greg Hoffman

Name of Operator: NOBLE ENERGY INC

Phone: (346) 287-1751

Address: 1001 NOBLE ENERGY WAY

Fax:

City: HOUSTON State: TX Zip: 77070

Email: greg.hoffman@nblenergy.com

For "Intent" 24 hour notice required,

Name: Evins, Bret

Tel: (970) 420-6699

COGCC contact:

Email: bret.evins@state.co.us

API Number 05-123-30849-00

Well Name: 70 Ranch USX BB

Well Number: 27-17

Location: QtrQtr: NENE Section: 27 Township: 5N Range: 63W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.373981

Longitude: -104.416906

GPS Data:

Date of Measurement: 10/27/2010

PDOP Reading: 4.8

GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment:

☐ Dry☒ Production Sub-economic☐ Mechanical Problems☐ Other

Casing to be pulled:

☐ Yes☒ No

Estimated Depth:

Fish in Hole:

☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------|-----------|-----------|----------------|---------------------|------------|
| CODELL | 6568 | 6578 | | | |
| J SAND | 7028 | 7076 | | | |
| NIOBRARA | 6314 | 6474 | | | |

Total: 3 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF | 12+1/4 | 8+5/8 | 24 | 560 | 257 | 560 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | 11.6 | 7,265 | 580 | 7,265 | 2,174 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6976 with 2 sacks cmt on top. CIPB #2: Depth 6262 with 2 sacks cmt on top.
CIBP #3: Depth 2198 with 2 sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

| | | | | | |
|-----------|--------------------|--------------|-----|------------------|---------------------------------------|
| Set _____ | sks cmt from _____ | ft. to _____ | ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ | sks cmt from _____ | ft. to _____ | ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ | sks cmt from _____ | ft. to _____ | ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ | sks cmt from _____ | ft. to _____ | ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ | sks cmt from _____ | ft. to _____ | ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |

Perforate and squeeze at 1240 ft. with 340 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Stephanie Dionne

Title: Operations Tech Date: _____ Email: stephanie.dionne@nblenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

| | |
|--|--|
| | |
|--|--|

Attachment Check List

Att Doc Num

Name

| | |
|-----------|------------------|
| 402166821 | WELLBORE DIAGRAM |
|-----------|------------------|

| | |
|-----------|------------------|
| 402166822 | WELLBORE DIAGRAM |
|-----------|------------------|

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

| | | |
|--|--|---------------------|
| | | Stamp Upon Approval |
|--|--|---------------------|

Total: 0 comment(s)