

FORM
6
Rev
11/20

State of Colorado
Energy & Carbon Management Commission



DE	ET	OE	ES
Document Number: 403483558			
Date Received: 08/01/2023			

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: <u>66190</u>	Contact Name: <u>Kit Chambers</u>
Name of Operator: <u>OMIMEX PETROLEUM INC</u>	Phone: <u>(214) 5497215</u>
Address: <u>2501 HARWOOD ST STE 1238</u>	Fax: _____
City: <u>DALLAS</u> State: <u>TX</u> Zip: <u>75201</u>	Email: <u>kchambers@ravenwoodlabs.com</u>
For "Intent" 24 hour notice required, Name: <u>St John, William (Cal)</u> Tel: <u>(720) 545-5624</u>	
COGCC contact: Email: <u>cal.stjohn@state.co.us</u>	

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number <u>05-125-10506-00</u>	Well Number: <u>13-3-4-43</u>
Well Name: <u>FRANK</u>	
Location: QtrQtr: <u>SWSW</u> Section: <u>3</u> Township: <u>4N</u> Range: <u>43W</u> Meridian: <u>6</u>	
County: <u>YUMA</u> Federal, Indian or State Lease Number: _____	
Field Name: <u>BALLYNEAL</u> Field Number: <u>1970</u>	

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.337820 Longitude: -102.166250

GPS Data: GPS Quality Value: 3.4 Type of GPS Quality Value: PDOP Date of Measurement: 03/03/2007

Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____

Casing to be pulled: Yes No Estimated Depth: 1675

Fish in Hole: Yes No If yes, explain details below

Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below

Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2188	2198			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	9+7/8	7	J55	20	0	491	216	491	0	VISU
1ST	6+1/4	4+1/5	J55	10.5	0	2467	75	2467	1700	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2138 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 25 sks cmt from 1725 ft. to 1625 ft. Plug Type: STUB PLUG Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 25 sacks half in. half out surface casing from 541 ft. to 441 ft. Plug Tagged:
Set 15 sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
Surface Plug Setting Date: _____ Cut and Cap Date: _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Kit Chambers
Title: Vice President Date: 8/1/2023 Email: kchambers@ravenwoodlabs.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 8/4/2023

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 2/3/2024

COA Type	Description
	<p>Bradenhead Testing Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <p>1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p>
	<p>Consistent with Rule 911.a, a Form 27 must be approved prior to cut and cap, conducting flowline abandonment, or removing production equipment. Allow 30 days for Director review of the Form 27; include the Form 27 document number on the Form 44 for offsite flowline abandonment (if applicable) and on the Form 6 Subsequent.</p>
	<p>Properly abandon flowlines per Rule 1105. If flowlines will be abandoned in place, include with the Form 27: pressure test results conducted in the prior 12 months as well as identification of any document numbers for a COGCC Spill/Release Report, Form 19, associated with the abandoned line.</p>
	<p>Plugging</p> <p>1) Provide electronic Form 42 Notice of MIRU 2 business days ahead of operations and electronic Form 42 Notice of Plugging Operations 48 hours prior to mobilizing for plugging operations. 2) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained. 3) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Wait on cement(WOC) a minimum of 4 hrs before tagging a plug. Tag at tops specified or shallower. Notify COGCC Area Engineer before adding cement to previous plug. 4) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap. 5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 6) Operator must wait a sufficient time on all plugs to achieve the intended design. If at any time during the plugging there is evidence of previously unreported pressure or fluid migration, contact COGCC Area Engineer before continuing operations. 7) Plugging procedure has been modified as follows, Plug #1 - 2138', CIBP with 2 sx of cement. Plug #2 - 1725-1675', 25 sx stub plug, WOC and tag. Plug #3 - 541-441', 25 sx cement plug, WOC and tag at 441' or shallower if cement is not brought to the surface and remains there. Plug #4 - 50' of cement at the surface in the casing per COA #4.</p>
4 COAs	

Attachment List

Att Doc Num	Name
403483558	FORM 6 INTENT SUBMITTED
403483636	WELLBORE DIAGRAM
403483639	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Groundwater=High Plains Deepest water well=380(1mi) Log=1/27/2007 HP base behind surface casing	08/04/2023
OGLA	OGLA review complete. Well is not in a HPH, not near surface waters or wetlands, and no nearby RBUs.	08/03/2023

Total: 2 comment(s)