



<div>FORM 6</div> <div>Rev 11/20</div>	<div>State of Colorado</div> <div>Energy &amp; Carbon Management Commission</div> <div>1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109</div>	<div></div>	<table><tr><td>DE</td><td>ET</td><td>OE</td><td>ES</td></tr></table>	DE	ET	OE	ES																																								
	DE	ET	OE	ES																																											
<div>WELL ABANDONMENT REPORT</div> <div><p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p></div>			<div>Replug By Other Operator</div> <div>Document Number: 403649406</div> <div>Date Received:</div>																																												
<div><div>OGCC Operator Number: 47120</div><div>Contact Name: Lorena Ruiz</div><div>Name of Operator: KERR MCGEE OIL &amp; GAS ONSHORE LP</div><div>Phone: (970) 336-3535</div><div>Address: P O BOX 173779</div><div>Fax:</div><div>City: DENVER State: CO Zip: 80217-</div><div>Email: lorena_ruiz@oxy.com</div><div>For "Intent" 24 hour notice required, Name: Carlile, Craig Tel: (970) 629-8279</div><div>COGCC contact: Email: craig.carlile@state.co.us</div></div>																																															
<div>Type of Well Abandonment Report: <input checked="" type="checkbox"/> Notice of Intent to Abandon <input type="checkbox"/> Subsequent Report of Abandonment</div>																																															
<div><div>API Number 05-123-16730-00</div><div>Well Name: ULRICH Well Number: 22-8L</div><div>Location: QtrQtr: SENE Section: 22 Township: 3N Range: 67W Meridian: 6</div><div>County: WELD Federal, Indian or State Lease Number: 63605</div><div>Field Name: WATTENBERG Field Number: 90750</div></div>																																															
<div>Only Complete the Following Background Information for Intent to Abandon</div> <div><div>Latitude: 40.213366 Longitude: -104.869123</div><div>GPS Data: GPS Quality Value: Type of GPS Quality Value: Date of Measurement:</div><div>Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems</div><div><input checked="" type="checkbox"/> Other Re-entry</div><div>Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Estimated Depth:</div><div>Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below</div><div>Details:</div></div>																																															
<div>Current and Previously Abandoned Zones</div> <table><tr><th>Formation</th><th>Perf. Top</th><th>Perf. Btm</th><th>Abandoned Date</th><th>Method of Isolation</th><th>Plug Depth</th></tr><tr><td>CODELL</td><td>7266</td><td>7276</td><td>11/13/2003</td><td>B PLUG CEMENT TOP</td><td>7172</td></tr></table> <div>Total: 1 zone(s)</div>				Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth	CODELL	7266	7276	11/13/2003	B PLUG CEMENT TOP	7172																																
Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth																																										
CODELL	7266	7276	11/13/2003	B PLUG CEMENT TOP	7172																																										
<div>Casing History</div> <table><tr><th>Casing Type</th><th>Size of Hole</th><th>Size of Casing</th><th>Grade</th><th>Wt/Ft</th><th>Csg/Liner Top</th><th>Setting Depth</th><th>Sacks Cmt</th><th>Cmt Btm</th><th>Cmt Top</th><th>Status</th></tr><tr><td>SURF</td><td>12+1/4</td><td>8+5/8</td><td>J-55</td><td>24</td><td>0</td><td>513</td><td>400</td><td>513</td><td>0</td><td>VISU</td></tr><tr><td>1ST</td><td>7+7/8</td><td>2+3/8</td><td>I-80</td><td>4.7</td><td>0</td><td>7397</td><td>575</td><td>7397</td><td>6100</td><td>CBL</td></tr><tr><td>S.C. 1.1</td><td>7+7/8</td><td>2+3/8</td><td>I-80</td><td>4.7</td><td>0</td><td>7397</td><td>230</td><td>5200</td><td>4130</td><td>CBL</td></tr></table>				Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status	SURF	12+1/4	8+5/8	J-55	24	0	513	400	513	0	VISU	1ST	7+7/8	2+3/8	I-80	4.7	0	7397	575	7397	6100	CBL	S.C. 1.1	7+7/8	2+3/8	I-80	4.7	0	7397	230	5200	4130	CBL
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status																																					
SURF	12+1/4	8+5/8	J-55	24	0	513	400	513	0	VISU																																					
1ST	7+7/8	2+3/8	I-80	4.7	0	7397	575	7397	6100	CBL																																					
S.C. 1.1	7+7/8	2+3/8	I-80	4.7	0	7397	230	5200	4130	CBL																																					

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 260 with 80 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 285 sks cmt from 3500 ft. to 3000 ft. Plug Type: OPEN HOLE Plug Tagged: ☐  
Set 285 sks cmt from 2400 ft. to 1900 ft. Plug Type: OPEN HOLE Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐  
Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged: ☐

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)

Set 360 sacks half in. half out surface casing from 1370 ft. to 463 ft. Plug Tagged: ☐

Set 80 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Number of Days from Setting Surface Plug  
Surface Plug Setting Date: \_\_\_\_\_ Cut and Cap Date: \_\_\_\_\_ to Capping or Sealing the Well: \_\_\_\_\_

\*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_

Type of Cement and Additives Used: \_\_\_\_\_

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

**Signage for P&As:**

Prior to commencing operations, KMG will post signs in conspicuous locations. The signs will indicate plugging and abandonment operations are being conducted, the well name, well, and the Operator's contact information. Signs will be placed so as not to create a potential traffic hazard.

**Notifications:**

Courtesy notifications will be sent to all parcel owners with building units within 1,500 feet of the location letting them know about out plugging and abandonment operations and providing contact information for Kerr McGee's response line and online resources.

**Wellbore Pressure:**

In some cases, wellbore pressure drawdown operations may occur approximately 1-2 days prior to Move In Rig Up (MIRU) of the workover rig. This is conducted to allow for reduced time that the workover rig is needed on location. These operations will be conducted in accordance with Form 4 and/or Form 6 requirements.

**Water:**

Water will be placed on dirt access roads to mitigate dust as needed.

**Lighting:**

Operations are daylight-only; no lighting impacts are anticipated from operations.

**Noise:**

Operations will be in compliance with Table 423-1 requirements. Based off the rig sound signature, rig orientation will be considered to reduce noise levels to nearby building units.

**Environmental Concerns:**

This location was reviewed using a desktop method to review publicly available wildlife data (including CPW & ECMC data) as well as internal wildlife datasets and aerial imagery. All field personnel are trained to identify wildlife risks and raise concerns noticed during operations with the KMOG Health, Safety, and Environment (HSE) department.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Lorena Ruiz  
Title: Regulatory Tech Date: \_\_\_\_\_ Email: lorena\_ruiz@oxy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

<u>COA Type</u>	<u>Description</u>
-----------------	--------------------

0 COA	
-------	--

### Attachment List

<u>Att Doc Num</u>	<u>Name</u>
403649415	LOCATION PHOTO
403649416	WELLBORE DIAGRAM
403649417	PROPOSED PLUGGING PROCEDURE
403649418	WELLBORE DIAGRAM
403649419	SURFACE OWNER CONSENT

Total Attach: 5 Files

### General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
		Stamp Upon Approval

Total: 0 comment(s)