


FORM 6 Rev 11/20	State of Colorado Energy & Carbon Management Commission				DE	ET	OE	ES		
	1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109				Replug By Other Operator					
WELL ABANDONMENT REPORT					Document Number: 403860690					
<p>This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.</p>					Date Received:					
ECMC Operator Number: 68900					Contact Name: Richard Murray					
Name of Operator: PETRO-LEWIS CORP					Phone: (970) 989-3092					
Address: UNDELIVERABLE AS ADDRESSED					Fax:					
City: DENVER State: CO Zip: 80201					Email: G.Richard.Murray@state.co.us					
For "Intent" 24 hour notice required, Name: Popejoy, Dusty Tel: (720) 822-1471										
ECMC contact: Email: dusty.popejoy@state.co.us										
Type of Well Abandonment Report: <input checked="" type="checkbox"/> Notice of Intent to Abandon <input type="checkbox"/> Subsequent Report of Abandonment										
API Number 05-077-08022-00										
Well Name: CURRIER					Well Number: 7-2 (OWP)					
Location: QtrQtr: SWNE Section: 2 Township: 9S Range: 93W Meridian: 6										
County: MESA					Federal, Indian or State Lease Number:					
Field Name: WILDCAT					Field Number: 99999					
Only Complete the Following Background Information for Intent to Abandon										
Latitude: 39.308703 Longitude: -107.733133										
GPS Data: GPS Quality Value: Type of GPS Quality Value: Date of Measurement:										
Reason for Abandonment: <input type="checkbox"/> Dry <input type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems										
<input checked="" type="checkbox"/> Other Orphan well program										
Casing to be pulled: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Estimated Depth:										
Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below										
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No If yes, explain details below										
Details:										
Current and Previously Abandoned Zones										
Formation Perf. Top Perf. Btm Abandoned Date Method of Isolation Plug Depth										
Total: 0 zone(s)										
Casing History										
Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	17+1/4	13+3/8	NA	48	0	508	610	508	0	VISU
1ST	8+3/4	7	NA	23,26	0	8844	150	8844	8350	CALC
OPEN HOLE	8+3/4				8844	9257				
Date Run: 7/22/2024 Doc [#403860690] Well Name: CURRIER 7-2 (OWP)					Page 1 of 3					

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 450 with 25 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 50 ft. to 0 ft. Plug Type: CASING Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____

*Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

This well is part of a larger OWP Plugging Project. This well was never completed, just drilled and shut-in. This well was PA and is possibly leaking. OWP is proposing a reentry to PA properly.

This is a resubmittal of approved Form 6 NOI #403323752

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Richard Murray

Title: OWP Specialist

Date: _____

Email: g.Richard.murray@state.co.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with ECMC Rules and applicable orders and is hereby approved.

ECMC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY LIST

Expiration Date: _____

COA Type	Description
0 COA	

ATTACHMENT LIST

Att Doc Num	Name
403860714	WELLBORE DIAGRAM

Total Attach: 1 Files

General Comments

User Group	Comment	Comment Date
		Stamp Upon Approval

Total: 0 comment(s)