

State of Colorado
Energy & Carbon Management Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203
Phone: (303) 894-2100 Fax: (303) 894-2109



ECMC RECEPTION

Receive Date:
08/07/2024

Document Number:
403880262

FIELD OPERATIONS NOTICE

The Form 42 shall be submitted as required by Rule, Notice to Operators, Policy, or Condition of Approval. A Form 42 Update shall be submitted to revise the scheduled date or time on a previous Form 42 - Advance Notice of Field Operations. A Form 42 Update must be for the same well, location, or facility and for the same Field Operation as a previous Form 42. NOTE: Operator's Contact for Advance Notices of Field Operations should be available 24 hours a day, 7 days a week and should have the most current scheduling information for the operation. Operator's Contact for other notices should be able to respond to questions regarding the reported information.

Update of a previous Form 42 Notice NO

Entity Information

ECMC Operator Number: <u>44390</u>	Contact Person: <u>Jim Javernick</u>
Company Name: <u>JAVERNICK OIL</u>	Phone: <u>(719) 671-3787</u>
Address: <u>3040 E MAIN</u>	Fax: <u>()</u>
City: <u>CANON CITY</u> State: <u>CO</u> Zip: <u>81212</u>	Email: <u>javernick1@gmail.com</u>
API #: <u>05 - 043 - 40051 - 00</u>	Facility ID: <u>259219</u>
Location ID: <u>322281</u>	<input checked="" type="checkbox"/> Submit By Other Operator
Facility Name: <u>MESSER WELL 1</u>	
Sec: <u>33</u> Twp: <u>19S</u> Range: <u>69W</u> QtrQtr: <u>SESE</u>	Lat: <u>38.346811</u> Long: <u>-105.109395</u>

START OF PLUGGING OPERATIONS - 48-hour notice required

Date: 08/09/2024 Time: 07:00 (HH:MM)

Are Plugging Operations for this Well anticipated to last for longer than one day? Yes

If YES, briefly describe the planned activities and the estimated duration of these operations:

Day 1; MIRUSU; Pump in water and remove Wellhead. Determine casing string(s) in this turn-of the-century drilled well (sometime between 1863-1910). Day 2: RU casing jacks and pull casing or cut off and pull and lay down casing. Run in hole and set wooden plug and cap with 2 sx sakrete. let set overnight. Day 3: Fill well to surface with 10-sack grout mix (well mix cement used in Fremont county). Cut casing 4' below ground level. At end of day, weld on steel I.D. Plate. Day 4: RDSU.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct and complete.

Print Name: Liz Harkins Email: lharkins@fremontpetroleum.com

Signature: _____ Title: Agent Date: 08/07/2024