

OIL AND GAS CONSERVATION COMMISSION
DEPARTMENT OF NATURAL RESOURCES
OF THE STATE OF COLORADO

RECEIVED



00043542

File in duplicate for Patented and Federal lands.
File in triplicate for State lands.

JUL 22 1974

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER WATER INJECTION WELL

2. NAME OF OPERATOR
CHEVRON OIL CO, WESTERN DIVISION

3. ADDRESS OF OPERATOR
RANGELY, COLORADO 81648

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
1586' NSL; 1865' WEL OF SEC. 3, T1N, R102W, 6th PM
At proposed prod. zone
NWSE

5. LEASE DESIGNATION AND SERIAL NO.
PATENTED

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
RANGELY WEBER SAND

8. FARM OR LEASE NAME
GENTRY

9. WELL NO.
4 D

10. FIELD AND POOL, OR WILDCAT
RANGELY WEBER SAND

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
SEC. 3.
T1N R102W

12. COUNTY
RIO BLANCO

13. STATE
COLO.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)
RT - 5218

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON <input checked="" type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Date of work AFTER AUGUST 1, 1974

It is proposed to plug and abandon this well as follows:

1. Rig up and pull tubing.
2. Set 100' cement plug through a retainer, set +50' above 7" casing shoe.
3. Set a 2-3 sacks cement plug on top of the retainer.
4. Pump 150 sacks cement down the 7"-surface pipe annulus.
5. Lay a 30' cement plug in the top of the 7" casing.
6. Weld a plate over casing head and install marker.
7. Remove or bury cement pumping unit foundation and "dead men".
8. Clean up all loose pipe, fittings, debris, etc. from location.
9. Scarify non grassy areas and plant seed (8-10#/acre), avoid further disturbance of surface conditions.

DVR	
FJP	
HHM	
JAM	✓
JJD	✓
GCH	
OGM	

18. I hereby certify that the foregoing is true and correct

SIGNED J.A. THOMPSON TITLE UNIT SUPT. DATE 7-19-74

(This space for Federal or State office use)

APPROVED BY [Signature] TITLE DIRECTOR DATE JUL 24 1974

CONDITIONS OF APPROVAL, IF ANY: