

FORM
6
Rev
12/05

State of Colorado
Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:
400367679

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175 Contact Name: Jeff Glossa
 Name of Operator: PDC ENERGY INC Phone: (303) 831-3972
 Address: 1775 SHERMAN STREET - STE 3000 Fax: (303) 860-5838
 City: DENVER State: CO Zip: 80203 Email: Jeffrey.Glossa@PDCE.com

For "Intent" 24 hour notice required, Name: MONTOYA, JOHN Tel: (970) 3974124
COGCC contact: Email: john.montoya@state.co.us

API Number 05-123-12663-00 Well Number: 1
 Well Name: BAUER
 Location: QtrQtr: NWNW Section: 4 Township: 5N Range: 64W Meridian: 6
 County: WELD Federal, Indian or State Lease Number: 56540
 Field Name: KERSEY Field Number: 44600

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.433504 Longitude: -104.562429
 GPS Data:
 Date of Measurement: 02/09/2010 PDOP Reading: 2.5 GPS Instrument Operator's Name: Robert Girillego
 Reason for Abandonment: Dry Production for Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: 6200
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Code	Perf. Top	Perf. Bottom	Date	Method of Isolation	Plug Depth
CODELL	CODL	6858	6868			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	306	210	306	0	CALC
1ST	7+7/8	4+1/2	12	6,977	160	6,977	6,200	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6350 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 6225 ft. to 6175 ft. Plug Type: STUB PLUG Plug Tagged:
Set 250 sks cmt from 4200 ft. to 3500 ft. Plug Type: OPEN HOLE Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)

Set 250 sacks half in. half out surface casing from 650 ft. to 0 ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

PDC Energy intends to plug the Bauer 1 following the procedure below

Existing Perforations
CODL 6858-6868

Casing Strings
Surface 8 5/8" @ 306' w/ TOC @ 0'
Production 4 1/2" @ 6977" w/ TOC est @ 6200'

Procedure

MIRU wireline and run CBL
RDMO wireline
Identify TOC and locate free point in the production casing (estimate 6200')
MIRU, TIH w/ CIBP and set @ 6350', Dump 2 sx cmt
TIH with casing cutter cut and pull 4 1/2" casing
TIH and set 50' plug at casing stub
Tag plug
Set cmt plug 4200-3500
Tag plug
Set cmt plug below Fox Hills to surface (650-0)

If unable to pull casing PDC will contact COGCC for plugging modifications.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Jeff Glossa

Title: Sr Engineering Tech

Date: _____

Email: Jeffrey.Glossa@PDCE.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

Attachment Check List

Att Doc Num	Name
400367687	WELLBORE DIAGRAM
400367689	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)