

WORKOVER PROCEDURE

WELL NAME: Trebor B11-22 DATE: 7/24/2013
LOCATION:
Qtr/Qtr: SENE Section: 11 Township: 5N Range: 64W
COUNTY: WELD STATE: CO API #: 05-123-30733

ENGINEER: Brittany Smyth 7 Day Notice Sent:
(Please notify Engineer of any major Do not start operations until:
changes prior to work) Notice Expires:

OBJECTIVE: Annular Fill

WELL DATA: Surface Csg: 8 5/8" 32# 576' KB Elevation: 4616'
Surface Cmt: 576' GL Elevation: 4600'
Long St Csg: 4 1/2" 11.6# N-80 6883' TD: 6893'
Long St Cmt: 1860' - TOC PBTB: 6814'
Long St Date: 1/12/2010

Plug Back (Sand or CIBP): TAG
Perforation Interval (1): NIO 6446'- 6630'
Perforation Interval (2): CODELL 6719'- 6732'
Perforation Interval (3):

Tubing: 2 3/8" 4.7# @ 6318' Rods:
Pump:
Misc.:

PRODUCTION STATUS: Producing - 25.2 BOEPD
COMMENTS: Base Fox Hills @ 258'

PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
2) Control well with kill fluid
3) POOH 2 3/8" tubing
4) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBTB (tally in). TOOH
5) RIH w/RBP. Set RBP @ +/-6396', spot 2 sx of sand on top of RBP. Test RBP 2,000psi. TOOH
6) Bleed off bradenhead, unland casing
7) Trip in 1 1/4" tubing down annular w/ mule shoe to 1300', condition hole.
8) RU cement crew, pump 144 sxs 15.8ppg "G" neat cement to cover the interval 800'-1200'.
9) POOH with 1 1/4" tubing, land casing.
10) SI well overnight, run CBL recording new cement depths
11) Clean out hole