

WORKOVER PROCEDURE

WELL NAME: Trebor B11-20 DATE: 7/24/2013

LOCATION: Qtr/Qtr: SENW Section: 11 Township: 5N Range: 64W
COUNTY: WELD STATE: CO API #: 05-123-30731

ENGINEER: Brittany Smyth 7 Day Notice Sent:
(Please notify Engineer of any major changes prior to work) Do not start operations until:
Notice Expires:

OBJECTIVE: Annular Fill

WELL DATA: Surface Csg: 8 5/8" 32# J-55 564' KB Elevation: 4615'
Surface Cmt: 564' GL Elevation: 4599'
Long St Csg: 4 1/2" 11.6# N-80 6883' TD: 6898'
Long St Cmt: 2622' - TOC PBTB: 6793'
Long St Date: 1/17/2010

Plug Back (Sand or CIBP): TAG
Perforation Interval (1): NIO 6452'- 6636'
Perforation Interval (2): CODELL 6728'- 6741'
Perforation Interval (3):

Tubing: N/A Rods:
Pump:
Misc.:

PRODUCTION STATUS: Producing - 20 BOEPD
COMMENTS: Base Fox Hills @ 257'

PROCEDURE:

- 1) MIRU Workover rig, pump & tank.
2) Control well with kill fluid
3) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBTB (tally in). TOOH
4) RIH w/RBP. Set RBP @ +/-6402', spot 2 sx of sand on top of RBP. Test RBP 2,000psi. TOOH
5) Bleed off bradenhead, unland casing
6) Trip in 1 1/4" tubing down annular w/ mule shoe to 1850', condition hole.
7) RU cement crew, pump 360 sxs 15.8ppg "G" neat cement to cover the interval 750'-1750'.
8) POOH with 1 1/4" tubing, land casing.
9) SI well overnight, run CBL recording new cement depths
10) Clean out hole