

WORKOVER PROCEDURE

WELL NAME: Trebor B11-18 DATE: 7/24/2013

LOCATION: Qtr/Qtr: SWNE Section: 11 Township: 5N Range: 64W

COUNTY: WELD STATE: CO API #: 05-123-30730

ENGINEER: Brittany Smyth 7 Day Notice Sent: Do not start operations until: Notice Expires:

OBJECTIVE: Annular Fill

WELL DATA: Surface Csg: 8 5/8" 32# J-55 553' KB Elevation: 4618' Surface Cmt: 553' GL Elevation: 4602' Long St Csg: 4 1/2" 11.6# N-80 6880' TD: 6894' Long St Cmt: 2340' - TOC PBTB: 6796' Long St Date: 1/2/2010

Plug Back (Sand or CIBP): LOG Perforation Interval (1): NIO 6454'- 6640' Perforation Interval (2): CODELL 6730'- 6743' Perforation Interval (3):

Tubing: 2 3/8" 4.7# J55 @ 6322' Rods: Pump: Misc.:

PRODUCTION STATUS: Producing - 6 BOEPD COMMENTS: Base Fox Hills @ 263'

PROCEDURE:

- 1) MIRU Workover rig, pump & tank. 2) Control well with kill fluid 3) POOH 2 3/8" tubing 4) RIH w/ Bit & Scraper. Tag fill if any. Clean out to PBTB (tally in). TOOH 5) RIH w/RBP. Set RBP @ +/-6404', spot 2 sx of sand on top of RBP. Test RBP 2,000psi. TOOH 6) Bleed off bradenhead, unland casing 7) Trip in 1 1/4" tubing down annular w/ mule shoe to 1850', condition hole. 8) RU cement crew, pump 360 sxs 15.8ppg "G" neat cement to cover the interval 750'-1750'. 9) POOH with 1 1/4" tubing, land casing. 10) SI well overnight, run CBL recording new cement depths 11) Clean out hole