

Document Number:  
400649490

Date Received:  
07/23/2014

**WELL ABANDONMENT REPORT**

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10261 Contact Name: Ryan Kaminky  
 Name of Operator: BAYSWATER EXPLORATION AND PRODUCTION Phone: (303) 7465195  
 Address: 730 17TH ST STE 610 Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80202 Email: rkaminky@bayswater.us

**For "Intent" 24 hour notice required,** Name: Gomez, Jason Tel: (970) 573-1277  
 COGCC contact: Email: jason.gomez@state.co.us

API Number 05-123-11482-00 Well Number: 13-29  
 Well Name: MOODY  
 Location: QtrQtr: SWSW Section: 29 Township: 5N Range: 65W Meridian: 6  
 County: WELD Federal, Indian or State Lease Number: 65494  
 Field Name: WATTENBERG Field Number: 90750

Notice of Intent to Abandon       Subsequent Report of Abandonment

*Only Complete the Following Background Information for Intent to Abandon*

Latitude: 40.364610 Longitude: -104.694530  
 GPS Data:  
 Date of Measurement: 03/09/2006 PDOP Reading: 6.0 GPS Instrument Operator's Name: LAUREN BARRINGER  
 Reason for Abandonment:  Dry     Production for Sub-economic     Mechanical Problems  
 Other loss of location access  
 Casing to be pulled:  Yes     No    Estimated Depth: \_\_\_\_\_  
 Fish in Hole:  Yes     No    If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes     No    If yes, explain details below  
 Details: \_\_\_\_\_

**Current and Previously Abandoned Zones**

| Formation       | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------------|-----------|-----------|----------------|---------------------|------------|
| NIOBRARA-CODELL | 6772      | 7097      |                |                     |            |

Total: 1 zone(s)

**Casing History**

| Casing Type | Size of Hole | Size of Casing | Weight Per Foot | Setting Depth | Sacks Cement | Cement Bot | Cement Top | Status |
|-------------|--------------|----------------|-----------------|---------------|--------------|------------|------------|--------|
| SURF        | 12+1/4       | 8+5/8          | 24              | 304           | 150          | 304        | 0          | VISU   |
| 1ST         | 7+7/8        | 4+1/2          | 11.5            | 7,190         | 850          | 7,190      | 2,900      | CALC   |

## Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6722 with 2 sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.  
 CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 40 sks cmt from 4000 ft. to 3900 ft. Plug Type: CASING Plug Tagged:   
 Set 20 sks cmt from 600 ft. to 450 ft. Plug Type: CASING Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Type: \_\_\_\_\_ Plug Tagged:   
 Perforate and squeeze at 1000 ft. with 40 sacks. Leave at least 100 ft. in casing 1000 CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
 Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth  
(Cast Iron Cement Retainer Depth)  
 Set \_\_\_\_\_ sacks half in. half out surface casing from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. Plug Tagged:   
 Set 20 sacks at surface  
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No  
 Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

### Additional Plugging Information for Subsequent Report Only

Casing Recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ inch casing Plugging Date: \_\_\_\_\_  
 \*Wireline Contractor: \_\_\_\_\_ \*Cementing Contractor: \_\_\_\_\_  
 Type of Cement and Additives Used: \_\_\_\_\_  
 Flowline/Pipeline has been abandoned per Rule 1103  Yes  No \*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Ryan Kaminky  
 Title: Operations Engineer Date: 7/23/2014 Email: rkaminky@bayswater.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:** \_\_\_\_\_ Expiration Date: \_\_\_\_\_

### Attachment Check List

| Att Doc Num | Name                        |
|-------------|-----------------------------|
| 400649490   | FORM 6 INTENT SUBMITTED     |
| 400652306   | WELLBORE DIAGRAM            |
| 400654956   | PROPOSED PLUGGING PROCEDURE |

Total Attach: 3 Files

## General Comments

| <u>User Group</u> | <u>Comment</u>   | <u>Comment Date</u>     |
|-------------------|--|-------------------------|
| Permit            | Sending form back to draft for wellbore diagrams and logs. | 7/29/2014<br>8:08:11 AM |

Total: 1 comment(s)