

WORKOVER PROCEDURE

WELL NAME: MONFORT GILCREST K08-09 **DATE:** 8/1/2014
LOCATION: Qtr/Qtr: NESE Section: 8 Township: 4N Range: 66W
COUNTY: WELD STATE: CO API #: 05-123-18038

ENGINEER: Stephanie Kolle/Jacob Eicher 7 Day Notice Sent: _____
(Please notify Engineer of any major Do not start operations until: _____
changes prior to work) Notice Expires: _____

OBJECTIVE: Annular Fill

WELL DATA: Surface Csg: 8 5/8" 24# @ 520' KB Elevation: 4709'
Surface Cmt: 520' GL Elevation: 4699'
Long St Csg: 4 1/2" 11.6# @ 7382' TD: 7390'
Long St Cmt: 3016' - 4146'; 5940' - 7382' PBTD: 7327'
Long St Date: 3/20/1994

Plug Back (Sand or CIBP): TBG TALLY
Perforation Interval (1): CODELL: 7203' - 7214'
Perforation Interval (2): _____
Perforation Interval (3): _____

Tubing: _____ Rods: _____
Pump: _____
Misc.: _____

PRODUCTION STATUS: 0 BOEPD
COMMENTS: Base of Fox Hills @ 331'

PROCEDURE:

1) MIRU Workover rig, pump & tank.

2) Control well with kill fluid

NOTE: There is already a RBP in place, one does not need to be set.

3) Bleed off bradenhead, unland casing

4) Trip in 1 1/4" tubing down annular w/ mule shoe to 1711', condition hole.

5) RU cement crew, pump 360 sxs 15.8ppg "G" neat cement to cover the interval 730'-1730'.

6) POOH with 1 1/4" tubing, land casing.

7) SI well overnight, run CBL recording new cement depths