

FORM
6Rev
12/05

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

400702093

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 47120

Contact Name: REBECCA HEIM

Name of Operator: KERR MCGEE OIL & GAS ONSHORE LP

Phone: (720) 929-6361

Address: P O BOX 173779

Fax: (720) 929-7361

City: DENVER State: CO Zip: 80217-

Email: REBECCA.HEIM@ANADARKO.COM

For "Intent" 24 hour notice required,

Name: Johnson, Randell

Tel: (303) 815-9641

COGCC contact:

Email: randell.johnson@state.co.us

API Number 05-123-20112-00

Well Name: IMPERIAL

Well Number: 15-31

Location: QtrQtr: NWNE Section: 15 Township: 1N Range: 68W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.057160

Longitude: -104.987050

GPS Data:

Date of Measurement: 04/02/2007

PDOP Reading: 2.6

GPS Instrument Operator's Name: Paul Tappy

Reason for Abandonment:

☐ Dry☒ Production for Sub-economic☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes☐ No

Estimated Depth: 1280

Fish in Hole: ☐ Yes☒ No

If yes, explain details below

Wellbore has Uncemented Casing leaks:

☐ Yes☒ No

If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7840	7858			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	807	570	807	0	CALC
1ST	7+7/8	4+1/2	11.6	7,957	375	7,957	4,170	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7750 with 45 sacks cmt on top. CIBP #2: Depth 80 with 25 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 45 sks cmt from 7750 ft. to 7075 ft. Plug Type: CASING Plug Tagged: ☒
Set 35 sks cmt from 4850 ft. to 4440 ft. Plug Type: CASING Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 235 sacks half in. half out surface casing from 1380 ft. to 607 ft. Plug Tagged: ☐

Set 25 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Plugging Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Imperial 15-31: Plug & Abandonment (SEE ATTACHED PROCEDURE)

1 Provide 48 hour notice to COGCC prior to rig up per request on approved Form 6 (e.g. call field coordinator, submit Form 42, etc.). Call IOC (970-506-5980) at least 24 hours prior to rig move. Request they catch and remove plunger, isolate production equipment, and remove any automation equipment prior to MIRU.

2 MIRU slickline. RIH to retrieve production equipment and tag for fill. Note tagged depth in OpenWells. RDMO slickline.

3 Prepare location for base beam equipped rig. Install perimeter fence as needed.

4 Check and report surface casing pressure. If surface casing is not accessible at ground level, re-plumb so valve is at ground level

5 MIRU WO rig. Kill well as necessary with water and biocide. ND wellhead. NU BOP.

6 Unland 2-3/8" tbg (245 total joints landed at 7788') and TOOHH standing back all 2-3/8" tubing.

7 MIRU wireline. RIH with junk basket/gauge ring (4-1/2" 11.6#) to 7800'. POOH. PU and RIH with CIBP (4-1/2", 11.6#) to set at 7750' (collars at 7726' & 7766'). POOH. RDMO wireline.

8 MIRU hydrotester. Hydrotest 2-3/8" tubing to 3000psi while TIH open ended. Tag CIBP set at 7750'. PUH just above CIBP and circulate all gas out of the hole. Pumping water with biocide, pressure test the CIBP and production casing to 1000psi for 15 minutes. If pressure test passes, proceed to next step; otherwise contact engineering.

9 MIRU cementing services. Establish circulation with water and pump 45 sx Class "G" cement with 20% silica flour, 0.4% CD-32 and 0.4% ASA-301 mixed at 15.8ppg and 1.38 cuft/sx (cement volumes based on 4-1/2" 11.6# casing capacity from 7750' to 7075' with no excess). Displace cement to estimated TOC at 7030' using approx. 27 bbls water. TOOHH and stand back 15 stands of 2-3/8" tubing so EOT at +/- 6830'. Reverse circulate using approx. 53 bbls water (2 times tubing volume) or until returns are clean.

RDMO cementing services.

10 TOOHH and land 2-3/8" EOT at 4850'. LD extra tubing.

11 MIRU cementing services. Establish circulation with water and pump 20 bbls sodium metasilicate followed by 35 sx Class "G" cement with 0.25 pps cello flake, 0.4% CD-32 and 0.4% ASA-301 mixed at 15.8ppg and 1.15 cuft/sx (cement volumes based on 4-1/2" 11.6# casing capacity from 4850' to 4440'). Displace cement to estimate TOC at 4380' using 17 bbls water. TOOHH and stand back 11 stands of 2-3/8" tubing so EOT at +/- 4180'. Reverse circulate using approx. 32 bbls water (2 times tubing volume) or until returns are clean. RDMO cementing services. WOC to set up per cementing company recommendation.

12 TOOHH and stand back 1380' of 2-3/8" tubing and LD extra tubing.

13 MIRU wireline. RIH to tag cement plug @ +/- 4380'. If cement is not above 4440' contact engineer, otherwise proceed to next step.

14 RIH and jet cut 4-1/2" production casing at 1280'. RDMO wireline. Circulate bottoms up and continue circulating to remove any gas from wellbore.

15 ND BOP. Install BOP on surface casing head with 4-1/2" pipe rams. Install 3000 psi ball valves on both casing head outlets. Install a choke or choke manifold on one outlet.

16 TOOHH and LD 1280' of 4-1/2" casing.

17 TIH w/ 2-3/8" tubing open ended to 1380' (100' inside the 4-1/2" stub).

18 MIRU cementing services. Establish circulation with water and pump 10 bbls SAPP mud flush, 20 bbls fresh water spacer, then balanced stub plug using 235 sx Type III cement with cello flake and CaCl₂ as necessary, mixed at 14.8 ppg and 1.33 cuft/sx (cement volumes based on 100' inside 4-1/2" casing, 473' in 8" hole with 40% excess, and 200' in 8-5/8" surface casing). RDMO cementing services.

19 TOOHH and LD 2-3/8" tubing until EOT at +/- 200'. Circulate down tubing and up surface casing/tubing annulus until returns are clean to ensure CIBP can

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: CHERYL LIGHT

Title: SR. REGULATORY ANALYST

Date: _____

Email: DJRegulatory@anadarko.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400702097	PROPOSED PLUGGING PROCEDURE
400702098	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>

Total: 0 comment(s)