

State of Colorado  
Oil and Gas Conservation Commission1120 Lincoln Street, Suite 801, Denver, Colorado 80203  
Phone: (303) 894-2100 Fax: (303) 894-2109

DE	ET	OE	ES
Document Number: <b>400819371</b>			
Date Received:			

## SUNDRY NOTICE

Submit a signed original. This form is to be used for general, technical and environmental sundry information. For proposed or completed operations, describe in full in Comments or provide as an attachment. Identify Well by API Number; identify Oil and Gas Location by Location ID Number; identify other Facility by Facility ID Number.

OGCC Operator Number:	47120	Contact Name	Cheryl Light
Name of Operator:	KERR MCGEE OIL & GAS ONSHORE LP		Phone: (720) 929-6461
Address:	P O BOX 173779		Fax: (720) 929-7461
City:	DENVER	State:	CO Zip: 80217-3779 Email: cheryl.light@anadarko.com

Complete the Attachment  
Checklist

OP OGCC

API Number :	05-	123	21625	00	OGCC Facility ID Number:	269137
Well/Facility Name:	PSC		Well/Facility Number:		15-10	
Location QtrQtr:	SWSE	Section:	10	Township:	3N	Range: 67W Meridian: 6
County:	WELD		Field Name:		WATTENBERG	
Federal, Indian or State Lease Number:						

Survey Plat		
Directional Survey		
Srfc Eqpmt Diagram		
Technical Info Page		
Other		

## CHANGE OF LOCATION OR AS BUILT GPS REPORT

☐ Change of Location \* ☐ As-Built GPS Location Report ☐ As-Built GPS Location Report with Survey

\* Well location change requires new plat. A substantive surface location change may require new Form 2A.

SURFACE LOCATION GPS DATA Data must be provided for Change of Surface Location and As Built Reports.

Latitude \_\_\_\_\_ PDOP Reading \_\_\_\_\_ Date of Measurement \_\_\_\_\_  
Longitude \_\_\_\_\_ GPS Instrument Operator's Name \_\_\_\_\_

## LOCATION CHANGE (all measurements in Feet)

Well will be: \_\_\_\_\_ (Vertical, Directional, Horizontal)

Change of **Surface** Footage **From** Exterior Section Lines:Change of **Surface** Footage **To** Exterior Section Lines:Current **Surface** Location **From** QtrQtr **SWSE** Sec **10**New **Surface** Location **To** QtrQtr \_\_\_\_\_ Sec \_\_\_\_\_Change of **Top of Productive Zone** Footage **From** Exterior Section Lines:Change of **Top of Productive Zone** Footage **To** Exterior Section Lines:Current **Top of Productive Zone** Location **From** Sec \_\_\_\_\_New **Top of Productive Zone** Location **To** Sec \_\_\_\_\_Change of **Bottomhole** Footage **From** Exterior Section Lines:Change of **Bottomhole** Footage **To** Exterior Section Lines:Current **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_New **Bottomhole** Location Sec \_\_\_\_\_ Twp \_\_\_\_\_

Is location in High Density Area? \_\_\_\_\_

Distance, in feet, to nearest building \_\_\_\_\_, public road: \_\_\_\_\_, above ground utility: \_\_\_\_\_, railroad: \_\_\_\_\_,  
property line: \_\_\_\_\_, lease line: \_\_\_\_\_, well in same formation: \_\_\_\_\_

Ground Elevation \_\_\_\_\_ feet Surface owner consultation date \_\_\_\_\_

FNL/FSL		FEL/FWL	
460	FSL	2149	FEL
Twp 3N	Range 67W	Meridian 6	
Twp	Range	Meridian	
			**
Twp	Range		
Twp	Range		
			**
			** attach deviated drilling plan

**CHANGE OR ADD OBJECTIVE FORMATION AND/OR SPACING UNIT**

<u>Objective Formation</u>	<u>Formation Code</u>	<u>Spacing Order Number</u>	<u>Unit Acreage</u>	<u>Unit Configuration</u>

**OTHER CHANGES**

☐ **REMOVE FROM SURFACE BOND** Signed surface use agreement is a required attachment

☐ **CHANGE OF WELL, FACILITY OR OIL & GAS LOCATION NAME OR NUMBER**

From: Name PSC Number 15-10 Effective Date: \_\_\_\_\_

To: Name \_\_\_\_\_ Number \_\_\_\_\_

☐ **ABANDON PERMIT: Permit can only be abandoned if the permitted operation has NOT been conducted. Field inspection will be conducted to verify site status.**

☐ WELL: Abandon Application for Permit-to-Drill (Form2) – Well API Number \_\_\_\_\_ has not been drilled.

☐ PIT: Abandon Earthen Pit Permit (Form 15) – COGCC Pit Facility ID Number \_\_\_\_\_ has not been constructed (Permitted and constructed pit requires closure per Rule 905)

☐ **CENTRALIZED E&P WASTE MANAGEMENT FACILITY:** Abandon Centralized E&P Waste Management Facility Permit (Form 28) – Facility ID Number \_\_\_\_\_ has not been constructed (Constructed facility requires closure per Rule 908)

OIL & GAS LOCATION ID Number: \_\_\_\_\_

☐ Abandon Oil & Gas Location Assessment (Form 2A) – Location has not been constructed and site will not be used in the future.

☐ Keep Oil & Gas Location Assessment (Form 2A) active until expiration date. This site will be used in the future.

**Surface disturbance from Oil and Gas Operations must be reclaimed per Rule 1003 and Rule 1004.**

☐ **REQUEST FOR CONFIDENTIAL STATUS**

☐ **DIGITAL WELL LOG UPLOAD**

☐ **DOCUMENTS SUBMITTED** Purpose of Submission: \_\_\_\_\_

**RECLAMATION****INTERIM RECLAMATION**

☐ Interim Reclamation will commence approximately \_\_\_\_\_

Per Rule 1003.e.(3) operator shall submit Sundry Notice reporting interim reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Interim reclamation complete, site ready for inspection.

Per Rule 1003.e(3) describe interim reclamation procedure in Comments below or provide as an attachment and attach required location photographs.

**Field inspection will be conducted to document Rule 1003.e. compliance**

**FINAL RECLAMATION**

☐ Final Reclamation will commence approximately \_\_\_\_\_

Per Rule 1004.c.(4) operator shall submit Sundry Notice reporting final reclamation is complete and site is ready for inspection when vegetation reaches 80% coverage.

☐ Final reclamation complete, site ready for inspection. Per Rule 1004.c(4) describe final reclamation procedure in Comments below or provide as an attachment.

**Field inspection will be conducted to document Rule 1004.c. compliance**

Comments:

**ENGINEERING AND ENVIRONMENTAL WORK**

☐ NOTICE OF CONTINUED TEMPORARILY ABANDONED STATUS

Indicate why the well is temporarily abandoned and describe future plans for utilization in the COMMENTS box below or provide as an attachment, as required by Rule 319.b.(3).

Date well temporarily abandoned \_\_\_\_\_ Has Production Equipment been removed from site? \_\_\_\_\_

Mechanical Integrity Test (MIT) required if shut in longer than 2 years. Date of last MIT \_\_\_\_\_

☐ SPUD DATE: \_\_\_\_\_

**TECHNICAL ENGINEERING AND ENVIRONMENTAL WORK**

Details of work must be described in full in the COMMENTS below or provided as an attachment.

☒ NOTICE OF INTENT                      Approximate Start Date    04/16/2015

☐ REPORT OF WORK DONE                      Date Work Completed    \_\_\_\_\_

- |  |   |  |
|--|---|--|
| <input type="checkbox"/> Intent to Recomplete (Form 2 also required) | <input type="checkbox"/> Request to Vent or Flare   | <input type="checkbox"/> E&P Waste Mangement Plan      |
| <input type="checkbox"/> Change Drilling Plan                        | <input checked="" type="checkbox"/> Repair Well   | <input type="checkbox"/> Beneficial Reuse of E&P Waste |
| <input type="checkbox"/> Gross Interval Change                       | <input type="checkbox"/> Rule 502 variance requested. Must provide detailed info regarding request. |  |
| <input type="checkbox"/> Other _____                                 | <input type="checkbox"/> Status Update/Change of Remediation Plans for Spills and Releases          |  |

## COMMENTS:

1 Well needs a single stage annular fill and casing pressure test.  
2 Gyro survey completed on this well 11/6/2014  
3 Contact field foreman or field coordinator at least 24 hrs prior to rig move. If not already completed, request that they catch and remove plunger, isolate production equipment and remove any automation equipment prior to the rig showing up. Install perimeter fence as needed.  
4 MIRU slickline. Fish PLE if necessary and tag fill (PBMD @ 7218').  
5 Prepare location for base beam rig.  
6 Spot 40 jts of 2-3/8" 4.7# J-55 8RD EUE tubing.  
7 Spot 45 jts of 1.66" 2.33# J-55 IJ tubing.  
8 Spot Alcomer 74L for pre-cement mud flush sweeps.  
9 Notify Ed Asuchak in drilling to have 10 ppg mud on standby.  
10 MIRU WO rig. Kill well with fresh water with biocide. ND wellhead, NU BOP.  
11 Run two 2" lines from starting head to return tanks.  
12 PU 8-10' landing joint with TIW safety valve on top and screw into the tubing hanger. Back out the lock down pins and pull up on the tubing string to break any possible sand bridges. Do not exceed 80% of tubing tensile strength, or 57,384-lb.  
13 Unseat tubing hanger and LD tubing hanger and landing joint. Install rubber wiper in stripping head.  
14 MIRU EMI equipment. TOO H with 2 3/8" tubing. EMI tubing while TOO H. Lay down joints with wall loss or penetrations >35%. Replace joints as necessary. Keep yellow and blue band tubing. Note joint number and depth of tubing leak(s) on production equipment failure report in OpenWells. Clearly mark all junk (red band) tubing sent to yard.  
15 TIH 2 3/8" tubing with 4.5" RBP (4.5" 11.6# I-80). Set RBP at +/- 6750' (collars at 6720' and 6762').  
16 Circulate gas out of well; pressure test RBP to 2,000 psi for 15 minutes (pressure test to make sure plug is set correctly).  
17 Spot 2 sx sand on top of RBP. TOO H with 2 3/8" tubing, stand back tubing.  
18 ND BOP, un-land 4 1/2" casing, RU dual-entry flange, NU BOP. Stretch calcs show that with a 53,000-lb pull weight there should be 24" of stretch. If casing cannot be safely un-landed, contact engineering for further support.  
19 PU and TIH with 1.66" 2.33# IJ tubing to 1200'. While tripping in, pump Alcomer 74L sweeps periodically based on visual inspection of returns with a final sweep at 1200'.  
20 Circulate 95 bbls with rig pump (circulate at least 1.5x annular volume from 1200') with 10 ppg mud spotted at the end until well is dead.  
21 TOO H 1.66" tubing to 1000'.  
22 MIRU cement company, establish circulation with biocide treated water and commence pumping cement job consisting of 5 bbls fresh water, 20 bbls sodium metasilicate, 5 bbls fresh water, and 45 bbl (190 sx) of Type III with 1/4 lb/sk cello-flake mixed at 14.8 ppg and 1.33 cuft/sk blended for a 3 hr pump time (cement from 1000' to 400').  
23 TOO H 1.66" tubing to 300' and reverse circulate 2X tbq volume to clean up. TOO H & LD remaining 1.66" tubing.  
24 Break lines, clean up with fresh water, RMDO cement company.  
25 ND BOP, ND dual entry flange, and re-land 4 1/2" casing. If needed, NU new WHI 7 1/16", 5000 psi flanged tubing head complete w/ 5000 psi rated casing valves and NU BOP. Leave well shut in minimum of 24 hours.  
26 MIRU WL and run CCL-GR-CBL-VDL from 3500' to 0'. If cement coverage is not above 400', contact Evans Engineering for further instructions. Email logs to Evans Engineering and DJVendors@anadarko.com. RDMO WL.  
27 ND BOP, NU 7 1/16", 5000 psi flanged tubing head adaptor w/ new 2 1/16", 5000 psi flanged master valve.  
28 MIRU hydrotester. Pressure test the casing and tubing head to 5000 psi for 15 minutes. If pressure test fails, contact Evans Engineering for possible change in procedure.  
29 ND WH, NU BOP.  
30 TIH with 2 3/8" tubing and retrieving head and tag sand above RBP at +/- 6750'. Circulate sand off RBP. Latch onto RBP and release RBP. TOO H standing back all 2 3/8" tubing and LD RBP.

## CASING AND CEMENTING CHANGES

Casing Type	Size	Of	/	Hole	Size	Of	/	Casing	Wt/Ft	Csg/LinTop	Setting Depth	Sacks of Cement	Cement Bottom	Cement Top

## H2S REPORTING

**Data Fields in this section are intended to document Sample and Location Data associated with the collection of a Gas Sample that is submitted for Laboratory Analysis.**

**Gas Analysis Report must be attached.**

H2S Concentration: \_\_\_\_\_ in ppm (parts per million)

Date of Measurement or Sample Collection \_\_\_\_\_

Description of Sample Point:

Absolute Open Flow Potential \_\_\_\_\_ in CFPD (cubic feet per day)

Description of Release Potential and Duration (If flow is not open to the atmosphere, identify the duration in which the container or pipeline would likely be opened for servicing operations.):

--

Distance to nearest occupied residence, school, church, park, school bus stop, place of business, or other areas where the public could reasonably be expected to frequent: \_\_\_\_\_

Distance to nearest Federal, State, County, or municipal road or highway owned and principally maintained for public use: \_\_\_\_\_

COMMENTS:

--

### **Best Management Practices**

**No BMP/COA Type**

**Description**

--	--

Operator Comments:

31 PU and TIH with 2 3/8" NC, 2 3/8" XN nipple, and 2 3/8" 4.7# J-55 tubing. Clean out as necessary. Land 2 3/8" tubing at +/- 7055' (1 joint above top Codell perf).  
32 RU rig lubricator. Broach tubing to XN nipple. RD rig lubricator.  
33 ND BOP, NU WH.  
34 MIRU hydrotester. Install 2 3/8" pup joint above master valve. Hydrotest wellhead to 5000 psi from below tubing head through master valve for 15 minutes.  
35 RMDO WO rig. Return well to production team.  
36 Clean location. Notify field foreman/field coordinator of finished work and turn well back over to production team.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: \_\_\_\_\_ Print Name: Cheryl Light

Title: Sr. Regulatory Analyst Email: DJRegulatory@anadarko.com Date: \_\_\_\_\_

Based on the information provided herein, this Sundry Notice (Form 4) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: \_\_\_\_\_ Date: \_\_\_\_\_

**CONDITIONS OF APPROVAL, IF ANY:**

### **General Comments**

**User Group**

**Comment**

**Comment Date**

--	--	--

Total: 0 comment(s)

### **Attachment Check List**

**Att Doc Num**

**Name**

400819375	OTHER
-----------	-------

Total Attach: 1 Files