

FORM
6Rev
12/05

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

400602050

Date Received:

05/15/2014

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 44390

Contact Name: Tom Menhennett

Name of Operator: JAVERNICK OIL

Phone: (719) 275-3040

Address: 3040 E MAIN

Fax: (719) 275-4590

City: CANON CITY State: CO Zip: 81212

Email: tbm3040@gmail.com

For "Intent" 24 hour notice required,

Name: LEONARD, MIKE

Tel: (719) 647-9715

COGCC contact:

Email: mike.leonard@state.co.us

API Number 05-043-40000-00

Well Name: CHEROKEE & PITTSBURG

Well Number: 86

Location: QtrQtr: NWSE Section: 29 Township: 19S Range: 69W Meridian: 6

County: FREMONT

Federal, Indian or State Lease Number:

Field Name: FLORENCE-CANON CITY

Field Number: 24600

☐ Notice of Intent to Abandon☒ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 38.362970

Longitude: -105.134720

GPS Data:

Date of Measurement: 08/15/2006

PDOP Reading: 2.0

GPS Instrument Operator's Name: Larry Robbins

Reason for Abandonment: ☐ Dry ☐ Production for Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☐ No Estimated Depth:Fish in Hole: ☐ Yes ☐ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☐ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
PIERRE			07/31/2012	CEMENT	600

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	7	5+5/8	26.70	130	0	0	0	CALC
1ST LINER	4+3/4	4+1/4	12.6	1,865	0	0	0	CALC
2ND LINER	3+7/8	3+1/2	8.7	2,450	0	0	0	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIPB #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIPB #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 10 sks cmt from 610 ft. to 600 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set 95 sks cmt from 600 ft. to 0 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: 200 ft. of 5+5/8 inch casing

Plugging Date: 08/02/2012

*Wireline Contractor: _____

*Cementing Contractor: Javernick Oil LLC

Type of Cement and Additives Used: Neat Cement

Flowline/Pipeline has been abandoned per Rule 1103 ☐ Yes ☐ No

*ATTACH JOB SUMMARY

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Tom Menhennett

Title: CFO Javernick Oil LLC

Date: 5/15/2014

Email: tbm3040@gmail.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: SUTPHIN, DIRK

Date: 5/4/2015

CONDITIONS OF APPROVAL, IF ANY:

COA Type

Description

--	--

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
400602050	FORM 6 SUBSEQUENT SUBMITTED
400602429	CEMENT JOB SUMMARY
400834969	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Agency	Received and uploaded final wbd. Deleted previously attached preplugging wbds.	5/4/2015 12:01:10 PM
Engineer	Operator provided corrections verbally by phone: Wood plug at 610', 10 sx sackrete, 9.5 yds (95 sx) 10 sack/cyd grout mix 600' to surface. Will provide final WBD.	4/29/2015 1:16:01 PM
Engineer	Requested confirm the plugging procedure 10 sks at 250' to 185' and 162 sx from 185' to surface. The Fremont Paving & Redi-Mix ticket is for 9.5 cyd. 6000 psi exterior Neat Cement. The inspection says they cut casing at 610', recovered 200'. Wood plug at 610' , 1o sx sackrete. Confirm how many cu.yds. was used and the admixture for the Neat Cement. Show how you get the number of cement sacks.	4/6/2015 1:09:28 PM
Engineer	operator requested form be returned to DRAFT for further documentation	1/27/2015 9:16:40 AM

Total: 4 comment(s)