

South Shale Ridge 10-15

COC 12735

NWSE Section 15, T8S, R98W, 6 PM, Mesa County

API # 05-077-08622

Plugging Procedure

1. MIRU SU. Install BOPE.
2. Excavate surface casinghead and monitor during operations.
3. Set a CIBP at 3150' and spot 2 sacks cement on top of plug.
4. Perforate 7" casing at 183' with 4 spf.
5. Establish circulation down 7" casing and out 9 $\frac{5}{8}$ " surface casing. Calculated volume is 12 bbls.
6. Mix and pump down 7" casing sufficient volume (60 sacks estimated) of 15.8 ppg Class G cement to circulate cement out 9 $\frac{5}{8}$ " surface casing valve. Shut down when good cement returns are observed at surface. Leave 7" casing full of cement.
7. Excavate around wellhead to 6' below grade. Cut off casing strings 4' below grade.
8. If cement has fallen inside 7" or annulus run 1" to a depth of 50' and pump additional sacks of cement to bring slurry to surface.
9. Weld steel plate with weep hole on casing stub.
10. Steel plate to have the following information:

Maralex Resources, Inc.
COC12735
South Shale Ridge 10-15
NWSE 15 8S 98W