

South Shale Ridge 9-22

COC 12735

NESE Section 22 T8S R98W 6PM Mesa County

API # 05-077-08615

1. MIRU SU. Install BOPE.
2. Set CIBP at 3494' and spot 2 sacks of cement on top of plug.
3. Perforate 4½" production casing at 1135' with 4 spf.
4. Set a CICR at 1035' and establish injection rate and pressure.
5. Mix and pump 30 sacks of 15.8 ppg Class G cement. Displace cement to retainer.
6. POOH laying down tubing.
7. Perforate 4½" casing at 175' with 4 spf.
8. Mix and pump down 4½" casing sufficient volume (50 sacks estimated) of 15.8 ppg Class G cement to circulate cement out 8⁵/₈" surface casing valve. Shut down when good cement returns are observed at surface. Leave 4½" casing full of cement.
9. Excavate around wellhead to 6' below grade. Cut off casing strings 4' below grade.
10. Weld steel plate with weep hole on casing stub with the following information:

Maralex Resources, Inc.
COC 12735
South Shale Ridge 9-22
NESE 22 8S 98W