

**WORKOVER PROCEDURE**

**WELL NAME:** BAILEY FEDERAL 18-01 **DATE:** 3/16/2016

**LOCATION:** Qtr/Qtr: NW/NE Section: 18 Township: 6N Range: 65W

Footages: 660 FNL & 1980 FEL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-10934

**ENGINEER:** JOHN HATCH 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24#, J-55 @ 317' KB Elevation: 44775'  
Surface Cmt: 300 sx GL Elevation: 4775'  
Long St Csg: 4 1/2", 11.60#, J-55/N-80 @ 7759' TD: 7759'  
Long St Cmt: 275 sx PBTD: 7298'  
Long St Date: 12/11/1982

Plug Back (Sand or CIBP): CIBP @ 7076'  
Perforation Interval (1): Niobrara Perforations 6832' - 7034'  
Perforation Interval (2): Codell Perforations 7146' - 7156'  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2 3/8" 4.70, J-55 @ 6827' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_  
**COMMENTS:** \_\_\_\_\_

- PROCEDURE:**
- 1) MIRU Workover rig, pump & tank.
  - 2) POOH w/ 2 3/8" tbg and lay down.
  - 3) RU WL. RIH w/ CIBP. Set CIBP @ 6782', dump bail 2 sx of cement on top.
  - 4) Unland casing. Cut casing off @ 2500'. POOH with casing laying down on trailer.
  - 5) RIH w/ workstring to pump 100 sx stub plug where csg was pulled. If maintain circulation, no need to tag plug.
  - 6) POOH w/ workstring to 375'. Pump 130 sx shoe plug. Cement to surface.
  - 7) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
  - 8) Cut surface casing off 6'-8' below ground.
  - 9) Clean up location. RDMOL.