

**WORKOVER PROCEDURE**

**WELL NAME:** MONFORT BB30-13 **DATE:** 5/9/2016

**LOCATION:** Qtr/Qtr: SW/SW Section: 30 Township: 5N Range: 63W

Footages: 672' FSL & 715' FWL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-18608

**ENGINEER:** Jonathan Pomerantz 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8" 24# @ 344' KB Elevation: 4591'  
Surface Cmt: 240 sx GL Elevation: 4581'  
Long St Csg: 2 7/8" 6.5# @ 6790' TD: 6831'  
Long St Cmt: 255 sx PBTD: 6758'  
Long St Date: 11/17/1994

Plug Back (Sand or CIBP): \_\_\_\_\_  
Perforation Interval (1): Niobrara Perforations 6423' - 6453'  
Perforation Interval (2): Codell Perforations 6615' - 6625'  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 1.66" 2.3# J-55 tbg @ 6598' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: \_\_\_\_\_

**PRODUCTION STATUS:** \_\_\_\_\_

**COMMENTS:** \_\_\_\_\_

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH w/ 1.66" tbg and lay down.
- 3) RU WL. RIH w/ CIBP. Set CIBP @ 6373', dump bail 2 sx of cement on top.
- 4) Unland casing. Cut casing off @ 2500'. POOH w/ casing laying down on trailer.
- 5) RIH w/ workstring to pump 100 sx stub plug where csg was pulled. If maintain circulation, no need to tag plug.
- 6) POOH w/ workstring to 630'. Pump 225 sx shoe plug. Cement to surface.
- 7) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 8) Cut surface casing off 6'-8' below ground.
- 9) Clean up location. Reclaim location. RDMO.