

**WORKOVER PROCEDURE**

**WELL NAME:** Cervi USX CC21-14 **DATE:** 5/16/2016

**LOCATION:** Qtr/Qtr: SESW Section: 21 Township: 4N Range: 63W

Footages: 660 FSL & 1980 FWL

**COUNTY:** WELD **STATE:** CO **API #:** 05-123-26038

**ENGINEER:** AJ Paine 7 Day Notice Sent: \_\_\_\_\_  
(Please notify Engineer of any major Do not start operations until: \_\_\_\_\_  
changes prior to work) Notice Expires: \_\_\_\_\_

**OBJECTIVE:** P&A

**WELL DATA:** Surface Csg: 8 5/8", 24#, J55 @ 600' KB Elevation: 4815'  
Surface Cmt: 290 sx GL Elevation: 4799'  
Long St Csg: 4 1/2", 11.6#, M-80 @ 7613' TD: 7630'  
Long St Cmt: 880 sx PBTD: 7460'  
Long St Date: 10/22/2007

Plug Back (Sand or CIBP): CIBP  
Perforation Interval (1): J Sand Perforations: 7227' - 7246'  
Perforation Interval (2): Dakota Perforations: 7510' - 7550'  
Perforation Interval (3): \_\_\_\_\_  
Tubing: 2 3/8", 4.7#, J-55 @ 7203' Rods: \_\_\_\_\_  
Pump: \_\_\_\_\_  
Misc.: SN & notched collar @ EOT

**PRODUCTION STATUS:** SI since 2014.

**COMMENTS:** \_\_\_\_\_

**PROCEDURE:**

- 1) MIRU Workover rig, pump & tank.
- 2) POOH and laydown 2 3/8" tubing.
- 3) RU WL. RIH to tag CIBP or fill. PBTD @ 7460' in 2008.
- 4) RIH w/ CIBP. Set @ 7177'.
- 5) RIH w/ workstring to pump 65 sx balance plug from CIBP to 6350' to cover Niobrara top.
- 6) Unland casing. Cut casing off @ 2200'. POOH and laydown 4 1/2" casing.
- 7) RIH w/ workstring to pump 100 sx stub plug where casing was pulled. If maintain circulation, no need to tag plug.
- 8) POOH w/ workstring to 700'. Pump 245 sx shoe plug. Cement to surface.
- 9) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 10) Cut surface casing off 6'-8' below ground.
- 11) Clean up location. Reclaim location. RDMO.