

## W 8-34 Wellbore Diagram

<b>Well</b>	<b>Pad</b>	<b>EU</b>	<b>API</b>
W 8-34	W 8-34 Pad	62053630	05-045-06513
<b>EUR (MMCF)</b>	<b>CUM (MMCF)</b>	<b>REM (MMCF)</b>	<b>Spud Date</b>
			10/21/1985
<b>Land Owner</b>	<b>First Sales</b>	<b>Production Field</b>	<b>Initial Cleanout</b>
	4/14/1986	NORTH PARACHUTE	
<b>Top Perf</b>	<b>Bottom Perf</b>	<b>Current EOT</b>	<b>EOT %</b>
1,554	1,702	NA	
<b>Last Tag</b>	<b>Tag Info</b>	<b>Amount</b>	<b>Fill/Rathole</b>
<b>New Tbg Depth</b>	<b>New EOT %</b>	<b>ft from Tag</b>	
<b>Bottom Surf Csg</b>	<b>Bottom Prod Csg</b>	<b>Float Collar</b>	
276	3,196		
<b>Average Inc</b>	<b>Max Inc</b>	<b>TOC</b>	
#DIV/0!		1.002	

Procedure: 1. MIRU WOR.  
 2. Blow well down. NO TBG, make sure there is no pressure before proceeding. Last blow down test was positive but pressure comes back within hours.  
 3. ND WH, NU BOP, test.  
 4. RU WL & TIH w/4-1/2" CIBP.  
 5. Set CIBP @ 1,680' and bail 2 sx cmt on top.  
 6. RDMO WL.  
 7. TIH w/SN & 2-3/8" TBG, land EOT @ 1,550'.  
 8. ND BOP, NU WH.  
 9. RDMO Service Unit, RTP.

