



UPV 05-05H3

P&A Procedure

Engineer: Josh Chebul (O: 720-587-2381; C: 720-412-8367)

3/16/2017

LOCATION:

Qtr/Qtr: SWNW Section: 5 Township: 5N Range: 63W
Footages: 1987 FNL & 655 FWL

COUNTY: WELD STATE: CO API #: 05-123-18860

WELL DATA:

Surface Csg: 7", 17#, H-40 @ 451' KB Elevation: 4687'
Surface Cmt: 200 sx GL Elevation: 4676'
Long St Csg: 3 1/2", 7.7#, N-80 @ 6924' TD: 6924'
Long St Cmt: 185 sx PBTD: 6877'
Long St Date: 2/3/1995

Plug Back (Sand or CIBP): Sand (2008)
Perforation Interval (1): Codell Perforations: 6764' - 6784'
Perforation Interval (2): _____
Perforation Interval (3): _____
Tubing: 1.66", 2.3#, J-55 @ 6737' Rods: _____
Pump: _____
Misc.: SN & notched collar @ EOT

PRODUCTION STATUS:

Producing
COMMENTS: Casing patch @ 4521' - 4523'

PROCEDURE:

- 1) Perform Bradenhead Form 17 if one hasn't been done w/in 6 months.
Recover any necessary samples per Form 6 COA; direct sample(s) to DIG/Precision contact for analysis.
- 2) MIRU Workover rig, pump & tank.
- 3) Unflange WH and POOH with production tubing.
- 4) RU WL. RIH w/ CIBP and set @ 6714'.
- 5) RIH with workstring to pump 12 sx cement plug on top of CIBP to properly cover Nio top (TOC 6276').
- 6) POOH w/ workstring to 2450'. Pump 22 sx balance plug from 2450' to 1953' for courtesy plug.
No need to tag plug if maintain circulation. POOH.
- 7) RIH w/ WL and cut production csg @ 651'. POOH w/ csg laying down on trailer.
- 8) RIH w/ workstring to 651' and pump 190 sx shoe plug. Cement to surface.
We will not try to run in casing 50' due to csg size.
- 9) SI, WOC. RIH. Tag shoe plug. Add cement if needed.
- 10) Cut surface casing off 6-8' below ground.
- 11) Clean up location. Reclaim location. RDMO.