

**Well Information**


---

Well Name	McPherson 3
API	05-123-05179
SHL	SENE 20 5N 61W
Latitude	40.388388
Longitude	-104.226435
Date of Plan	6/20/2017
Surface Casing Set Depth	161
TD	6874

## **Procedure**

---

- 1 Contact landowner and state representative 48 hours prior to commencing work on this well
- 2 Build temporary pad and access road for completion rig and cement unit
- 3 Cut off dry hole marker
- 4 Verify pipe size and weld on wellhead flange and riser
- 5 MIRU completion rig
- 6 MU BHA
- 7 RIH to 280' and drill out existing rock bridge
- 8 Continue to circulate mud to ensure hole clean out
- 9 POOH and LD BHA
  
- 10 TIH to 280'
- 11 RU Cementers
- 12 Pump 110 sx balanced plug to surface
- 13 POOH and LD tubing
- 14 RDMO completion rig
- 15 Dump 50' cement inside and outside surface casing
- 16 Cut off wellhead and riser to 4' below ground level
- 17 Weld on dry hole marker
- 18 Clean location and reclaim



**8 5/8" 24# Surface Set @ 161' MD**

### Cement Plug from 275' - Surface

5 1/2" 17# from 5030' - 6874'

### Cement Plug at 6674'

**7 7/8" Open Hole TD @ 6874' MD**

