

FORM
6Rev
05/18

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

401686811

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required.

Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10518

Contact Name: Brittany Rothe

Name of Operator: CONFLUENCE DJ LLC

Phone: (303) 226-9519

Address: 1001 17TH STREET #1250

Fax: (303) 226-9595

City: DENVER State: CO Zip: 80202

Email: brothe@confluencelp.com

For "Intent" 24 hour notice required,

Name: Precup, Jim

Tel: (303) 726-3822

COGCC contact:

Email: james.precup@state.co.us

API Number 05-001-08831-00

Well Name: HASKINS

Well Number: 1

Location: QtrQtr: SWSW Section: 4 Township: 1S Range: 65W Meridian: 6

County: ADAMS

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.989870

Longitude: -104.674860

GPS Data:

Date of Measurement: 01/21/2015

PDOP Reading: 2.2

GPS Instrument Operator's Name: DUANE RUSSELL

Reason for Abandonment: ☐ Dry ☐ Production Sub-economic ☐ Mechanical Problems☒ Other P&A'ing barely-economic well w/unknown cement coverage prior toCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	7866	7868			
J SAND	7942	7946			

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	unknown	261	165			
1ST	7+7/8	4+1/2	unknown	8,040				

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7816 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 44 sks cmt from 1410 ft. to 835 ft. Plug Type: CASING Plug Tagged: ☒

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 6000 ft. with 265 sacks. Leave at least 100 ft. in casing 5990 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 97 sacks half in. half out surface casing from 311 ft. to 0 ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☒ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Pull Tubing – Verify Production Casing Top, and Cement Bond

- 1.) MIRU workover rig, pump and tank. Blow down wellhead, rig up and pump 10-20 bbls lease water down tubing to control well.
- 2.) ND wellhead, NU BOP. Make up 2-3/8" pump joint and TIW to tubing string. PU on tubing, unland tubing and tubing hanger.
- 3.) Inspect via Tuboscope while TOO H w/ 7934' 2-3/8" tubing string. Lay down 1 joint.
- 4.) MIRU Wireline. RIH with Gyro Survey and CBL. Log well. Evaluate TOC of primary job and Fox Hills squeeze.

Plug Well

- 5.) RIH Wireline, set CIBP @ +/- 7,816', ~50' above top perf as long as CBL shows TOC above 7,816'.
- 6.) Dump 2 sacks cement on CIBP. Test casing to 500 psi.
- 7.) If test ok, RIH on Wireline a 1', 2 spf perf gun. Shoot @ +/- 6,000'. RD Wireline.
- 8.) RIH with tubing set 4-1/2" x 2-3/8" cement retainer, 2-3/8" stinger and 2-3/8" tubing. Set cement retainer @ +/- 5,990'.
- 9.) RU cementers. Squeeze 265 sxs of 15.8 ppg Class G 'neat' cement down tubing/ retainer and into squeeze holes.
- 10.) Sting out of cement retainer with 5 sacks in tubing and spot cement on top of retainer. PU 75' and circulate hole clean, TOO H with 2-3/8" tubing. Note any cement while circulating hole. WOC.
- 11.) RU wireline. Run CBL across squeeze. Confirm >400' cement coverage. If coverage is not adequate, repeat steps 7 – 9, shooting perf holes @ about TOC per CBL.
- 12.) Once adequate cement in annular of 4-1/2" production string is achieved, move to next.
- 13.) RIH with 2-3/8" tubing and mule shoe to 1,410', 100' below Fox Hills.
- 14.) RU cementers. Pump 44 sx balanced plug of 15.8 ppg Class G 'neat' cement across Fox Hills.
- 15.) POOH 2-3/8" tubing laying down. WOC.
- 16.) MIRU Wireline. Tag TOC to confirm height. If confirmed, then PU and shoot 2 squeeze holes at 311'.
- 17.) RU cementers to 4-1/2" casing. Pump 97 sx of 15.8 ppg Class G 'neat' for surface plug down casing and up annulus to surface.
- 18.) RDMO.

Reclaim

- 19.) Excavate around wellhead to 8' below grade, cut off 4-1/2" casing and 8-5/8" casing, weld on cap.
- 20.) Obtain GPS location data as per COGCC Rule 215.
- 21.) Backfill hole and reclaim surface to original conditions.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Brittany Rothe
Title: Engineering Manager Date: _____ Email: brothe@confluencelp.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: _____

COA Type

Description

--	--

Attachment Check List

Att Doc Num

Name

401686872	PROPOSED PLUGGING PROCEDURE
401686875	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)