

Quiver Unit #4 Recompletion Procedure:

1. TOH with tubing, rods & pump.
2. Perforate the St. Louis formation at 4979'-4983' (4spf).
3. TIH with RBP, packer and tubing.
4. Set RBP at ~5010' and packer at ~4950'.
5. Acidize St. Louis formation with 500 gals. 15% MCA and 1000 gals. MOD-202 acid.
6. Swab back load & swab test.
7. TOH with tubing, packer and RBP.
8. Run tubing, pump and rods for production.
9. Put back on production producing both the Spergen and St. Louis.