

Well Information

Well Name	Peters #16-34
API	05-123-07723
SHL	SESE 34 12N 63W 6 PM
Latitude	40.96035
Longitude	-104.412215
Date of Plan	12/13/2018
Surface Casing Set Depth	230
TD	8275

Procedure

- 1 Contact landowner and state representative 48 hours prior to commencing work on this well
- 2 Build temporary pad and access road for completion rig and cement unit if needed
- 3 Cut off dry hole marker if one exists. Locate wellbore.
- 4 Verify pipe size and weld on wellhead flange and riser
- 5 MIRU workover rig
- 6 MU BHA
- 7 RIH and drill out surface cement plug and casing shoe cement plug.
- 8 Circulate to ensure hole is clean
- 9 Continue RIH and cleaning out to 3000' MD. Circulate on bottom to ensure hole is clean.
- 10 POOH and LD BHA
- 11 TIH
- 12 RU Cementers
- 13 Pump 150 sx balanced plug from 3000' MD to 2620' MD
- 14 Pump 150 sx balanced plug from 1510' MD to 1190' MD
- 15 Pump 150 sx balanced plug from 800' MD to 393' MD
- 16 POOH and pump 99 sx balanced plug from 280' to surface
- 17 RDMO workover rig
- 18 Cut off wellhead and riser to 4' below ground level
- 19 Weld on dry hole marker
- 20 Clean location and reclaim