

FORM

6

Rev
11/20

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Replug By Other Operator

Document Number:

403371477

Date Received:

04/24/2023

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10651

Contact Name: Alex Waner

Name of Operator: VERDAD RESOURCES LLC

Phone: (303) 2049636

Address: 1125 17TH STREET SUITE 550

Fax:

City: DENVER State: CO Zip: 80202

Email: awaner@verdadresources.com

For "Intent" 24 hour notice required,

Name: Medina, Justin

Tel: (720) 471-0006

COGCC contact:

Email: justin.medina@state.co.us

Type of Well Abandonment Report:

☒ Notice of Intent to Abandon☐ Subsequent Report of Abandonment

API Number 05-123-07782-00

Well Name: SACK-HIETT

Well Number: 1

Location: QtrQtr: SWSW Section: 32 Township: 1N Range: 65W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.003428

Longitude: -104.693712

GPS Data: GPS Quality Value: 1.5 Type of GPS Quality Value: PDOP Date of Measurement: 04/05/2023

Reason for Abandonment: ☐ Dry ☐ Production Sub-economic ☐ Mechanical Problems☒ Other Re-entryCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☒ Yes ☐ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details: Tubing left cemented in from previous plug

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	7926	7949	06/15/1983	CEMENT	2200

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	unk	23	0	200	200	200	0	VISU
1ST	7+7/8	5	unk	18	0	8034	200	8034	7134	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 15 sks cmt from 7040 ft. to 6890 ft. Plug Type: CASING Plug Tagged: ☐
Set 30 sks cmt from 1264 ft. to 964 ft. Plug Type: CASING Plug Tagged: ☒
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 7090 ft. with 70 sacks. Leave at least 100 ft. in casing 7040 CICR Depth

Perforate and squeeze at 2550 ft. with 70 sacks. Leave at least 100 ft. in casing 2500 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 70 sacks half in. half out surface casing from 200 ft. to 0 ft. Plug Tagged: ☒

Set 0 sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

** Verdad will be using a closed-loop recirculating returns system consisting of shaker tank, mud tank, cuttings bin, and a utility tank to divert fluid to for solids to settle out, fluid for disposal, etc.**

1. File Form 42 2 days prior for P&A ops, notify COGCC field engineer of ops commencing
2. Familiarize all personnel with allowed access to location and areas allowed to be disturbed
3. Secure permission to access area and identify prospective well locations via satellite and survey data
4. Verify well location and excavate well
5. Once permission to begin work is secure, excavate area around well to sufficient size for safe access of casing, verify casing size, cut off cap, weld on slip collar w/ wellhead and riser, set cellar ring and back-fill
6. MIRU WO rig and beam, BOP, accumulator, rig pump, shaker tank, rig tank, 9.5ppg water-based mud, pipe float, 3-1/8" collars, 2-3/8" PH6 work string, power swivel
7. Rig up tubing tools, NU BHA and function test
8. Make up BHA consisting of: 2-3/8 PH6 string, 2x 3-1/8" drill collars, float, POBS, and 4 1/8" roller-cone bit
9. RIH and drill out previous cement plug from estimated 0-225'
10. Wash or ream in 5" cased hole to 2,200'
11. Circulate and condition hole
12. Drill cement until reaching tubing fish top. Contact engineer to discuss tripping for different bit better suited for cement/tubing milling
13. TOOH and laydown BHA
14. PU agreed upon BHA to mill tubing/cement
15. TIH to tubing fish top and mill tubing/cement until there are no more cement returns. If making good hole, continue to mill up tubing, if not, mill tubing to set up for a pipe body overshot
16. TOOH and MU new BHA consisting of 3-7/8" overshot w/ 2 7/8" grapple
17. RIH and latch onto tubing body. Perform stretch test to get rough idea of free point
18. MIRU eline WL truck. RIH w/ free point tool and determine free point of tubing
19. POOH w/ free point tool and prepare for chem cut
20. RIH w/ chem cut tool and cut tubing at lowest free point. POOH w/ WL and then POOH w/ 2-3/8" PH6 overshot with cut tubing
21. Contact engineer and fishing hand and MU BHA with overshot, jars, and intensifiers to attempt to jar our remaining tubing
22. POOH w/ jarred tubing, if full string does not come, assess depth of new fish top. If tubing fish top is below 7,090' proceed with cement job
23. Make up BHA consisting of: 4 1/8" tricone mill, XO, string float, 2-3/8 PH6 string and RIH to bottom of well
24. Circulate and condition hole. TOOH w/ tubing
25. RU WL, load hole and run CBL from deepest point to surface, this will determine where and if we need to annulus cement coverage
26. TIH w/ perforating guns and shoot 4 holes @ 7,090'. TOOH w/ perf guns. TIH w/ 5" CICR and set @ 7,040' MD. TOOH w/ setting tool and RD WL.
27. TIH w/ tbq and sting into CICR. Mix and pump 70 sks of Class G, 15.8 ppg, 1.15 yield cement into CICR. Pull out of CICR and leave 15 sks of Class G, 15.8 ppg, 1.15 yield cement on top of CICR. This will isolate the Niobrara Formation
28. Displace cement and POOH to 2,550', circulate and condition hole. POOH to surface
29. RU WL and TIH w/ perforating guns and shoot 4 holes @ 2,250'. TOOH w/ perf guns. TIH w/ 5" CICR and set @ 2,500' MD. TOOH w/ setting tool and RD WL.
30. TIH w/ tbq and sting into CICR. Mix and pump 70 sks of Class G, 15.8 ppg, 1.15 yield cement into CICR. Pull out of CICR and leave 15 sks of Class G, 15.8 ppg, 1.15 yield cement on top of CICR. This will isolate the Upper Pierre Formation
31. POOH to 1,264', circulate and condition hole. Prior to placing the Fox Hills Aquifer plug, verify that all fluid (liquid and gas) migration has been eliminated. If evidence of fluid migration or pressure remains, contact engineer to verify with the COGCC for an update to plugging orders
32. If no fluid migration, RU cementers and pump 30 sks of Class G, 15.8 ppg, 1.15 yield cement from 1,264' – 964' to isolate the Fox Hills Aquifer. Displace and POOH through cement and release cementers, ensure that

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Alex Waner
Title: Operations Engineer Date: 4/24/2023 Email: awaner@verdadresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 11/7/2023

COA Type	Description
	Verify existing cement coverage by CBL - submit to COGCC for verification of plugging orders prior to continuing plugging operations.
	If unable to wash down after drilling out plugs previously set, stop and contact COGCC engineer for an update to the plugging procedure.
	<p>1) Provide electronic Form 42 Notice of MIRU 2 business days ahead of operations and electronic Form 42 Notice of Plugging Operations 48 hours prior to mobilizing for plugging operations. These are two separate notifications, required by Rules 405.e and 405.l.</p> <p>2) Prior to placing cement above the base of the Upper Pierre (approximately 2190') : verify that all fluid (liquid and gas) migration has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders.</p> <p>3) Pump surface casing shoe plug only after isolation has been verified. If surface casing cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 150' or shallower and provide a minimum of 10 sx plug at the surface.</p> <p>4) Leave at least 100' of cement in the wellbore for each plug without mechanical isolation.</p> <p>5) With the Form 6 SRA operator must provide written documentation which positively affirms each COA listed above has been addressed.</p>
	Submit "as drilled" GPS data on Subsequent Report of Abandonment. GPS data must meet the requirements of Rule 216.
	Prior to commencing operations, the operator will post signs in conspicuous locations at intersections that will remain in place throughout the duration of the plug and abandonment activities. The signs will indicate plugging and abandonment operations are being conducted, the well name, well, and the applicable contact information. Signs will be placed so as not to create a potential traffic hazard.
	Operator will implement measures to capture, combust, or control emissions to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public health, welfare and the environment. Due to the proximity of building units (BUs) all blowdown gasses will be controlled.
	Due to close proximity of plugging and abandonment (PA) operations to RBUs/BUs, Operator will ensure compliance with maximum permissible noise levels in COGCC Rule Table 423-1 and install temporary sound walls, straw bales, or other BMPs to dampen noise if necessary.
	Due to close proximity to Residential Building Units (RBUs): prior to commencing operations, at a minimum, the operator will provide an informational sheet to the owners/occupants of RBUs that are nearby and adjacent to the parcel on which the well is located. The sheet will include the operator's contact information and the nature, timing, and expected duration of the P&A operations.
	Due to proximity to surface water, Operator will review the stormwater program and implement stormwater BMPs and erosion control measures as needed to prevent fine-grained sediment and impacted stormwater runoff from entering surface water.
9 COAs	

Attachment List

Att Doc Num	Name
403371477	WELL ABANDONMENT REPORT (INTENT)
403371495	PROPOSED PLUGGING PROCEDURE
403371496	WELLBORE DIAGRAM
403371497	WELLBORE DIAGRAM
403371498	LOCATION PHOTO
403374446	SURFACE OWNER CONSENT
403396183	FORM 6 INTENT SUBMITTED

Total Attach: 7 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Emailing operator regarding Niobrara cement volumes. Estimated 280' behind pipe. Wellbore diagram shows 200'. To be corrected on form 6 - subsequent.	05/03/2023
Engineer	DWR base of Fox Hills: 1214' Deepest water well within 1 mile: 1100' Base of Upper Pierre estimated: 2190' No CBL on file.	05/03/2023
OGLA	OGLA review complete and task passed.	04/28/2023
OGLA	Returned to Draft: Submitter is not a designated agent. Operator should submit a Form 1A for the current submitter and/or have a designated agent submit this Form. Registered as of 4/28/2023.	04/21/2023
Permit	Attached surface owner consent. Pass.	04/17/2023
Permit	Confirmed as-drilled well location. No other forms in process. Corrected formation on zones tab. Confirmed productive interval per docnum: 18214. Letter attached is not surface owner consent. RTD.	04/13/2023

Total: 6 comment(s)

SUSPENDED